

# SIEMENS

# SIEMENS



Siemens Aktiengesellschaft,  
issued by Communications,  
Haidenauplatz 1  
D-81667 Munich

© Siemens AG 2005  
All rights reserved. Subject to availability.  
Rights of modification reserved.

Siemens Aktiengesellschaft  
[www.siemens.com/sp65](http://www.siemens.com/sp65)

Designed for life

**SP65**

<b>Safety precautions</b> .....	3	<b>Phonebook</b> .....	36
<b>Overview of phone</b> .....	5	New entry .....	36
<b>Display symbols</b> .....	7	Calling	
<b>Getting started</b> .....	9	(searching for an entry) .....	37
Inserting the SIM card/ battery .....	9	Changing an entry .....	37
Inserting an RS MultiMediaCard™ .....	10	<Special books> .....	38
Charging the battery .....	11	<b>Call records</b> .....	39
<b>Switching on/off, PIN entry</b> .....	13	<b>Durat/charges</b> .....	40
Entering the PIN .....	13	<b>Inbox</b> .....	41
Emergency number (SOS) .....	13	<b>SMS</b> .....	42
<b>General instructions</b> .....	14	Writing/sending .....	42
Standby mode .....	14	Reading .....	44
Signal strength .....	14	Setting .....	46
Digital Rights Mgmt. (DRM) .....	14	<b>MMS</b> .....	48
Main menu .....	14	Creating an MMS .....	48
<b>Standard functions</b> .....	16	Templates .....	50
Highlighting mode .....	17	Sending .....	51
Menu speed dialling .....	17	Receiving .....	52
<b>Security</b> .....	18	Reading .....	53
PIN codes .....	18	Setting .....	54
Preventing accidental activation .....	19	<b>E-mail</b> .....	56
<b>Text entry</b> .....	20	Writing .....	56
<b>Calling</b> .....	24	Receiving/reading .....	57
<b>My items</b> .....	30	Setting .....	58
<b>Default book</b> .....	31	<b>Voice message/mailbox</b> .....	59
<b>Addressbook</b> .....	32	<b>Inst. message</b> .....	60
New entry .....	32	Start menu .....	60
Changing an entry .....	34	Login .....	61
Calling an entry .....	34	Contact lists .....	61
Groups .....	35	Starting Inst. message .....	64
		Msg. history .....	65
		Setting .....	65
		<b>CB services</b> .....	67

See also Index at the end of this User Guide

<b>Surf &amp; fun</b> .....	<b>68</b>	<b>Extras</b> .....	<b>105</b>
Internet .....	68	SIM services (optional) .....	105
Bookmarks .....	70	Alarm clock .....	105
Games and Applications .....	71	Calc. ....	106
Downl. assist. ....	71	Unit converter .....	107
<b>Setup</b> .....	<b>73</b>	Stopwatch .....	108
Profiles .....	73	Countdown .....	108
Themes .....	75	Sound recorder .....	108
Display setup .....	76	Remote synchronisation .....	109
Ringtones .....	78	Device manag. ....	110
Call setup .....	80	<b>Sound recorder</b> .....	<b>111</b>
Phone setup .....	82	<b>Media player</b> .....	<b>112</b>
Clock .....	84	<b>My stuff</b> .....	<b>113</b>
Connectivity .....	85	RS MultiMediaCard™ .....	114
Security .....	91	<b>Mobile Phone Manager</b> .....	<b>115</b>
Network .....	93	<b>Questions &amp; Answers</b> .....	<b>117</b>
Accessories .....	95	<b>Customer Care</b> .....	<b>120</b>
<b>My menu</b> .....	<b>96</b>	<b>Care and maintenance</b> .....	<b>122</b>
<b>Fast access</b> .....	<b>97</b>	<b>Product data</b> .....	<b>123</b>
Speed dialling keys .....	98	<b>Quality</b> .....	<b>124</b>
<b>Organiser</b> .....	<b>99</b>	<b>Accessories</b> .....	<b>125</b>
Calendar .....	99	<b>Guarantee certificate (UK)</b> .....	<b>127</b>
Appointments .....	100	<b>Guarantee certificate (IRL)</b> .....	<b>129</b>
Tasks .....	101	<b>SAR –</b>	
Notes .....	102	European Union (RTTE) .....	131
Missed appts. ....	102	<b>SAR – International (ICNIRP)</b> .....	<b>133</b>
Dictat.machine .....	103	<b>Menu tree</b> .....	<b>134</b>
Time zones .....	104	<b>Index</b> .....	<b>140</b>

See also Index at the end of this User Guide

# Safety precautions

## Information for parents

Please read the operating instructions and safety precautions carefully before use. Explain the content and the hazards associated with using the phone to your children.



Remember to comply with legal requirements and local restrictions when using the phone. For example in aeroplanes, petrol stations, hospitals or while driving.



Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. Keep at least 20 cm/9 inches between phone and pacemaker. When using the mobile phone hold it to the ear which is further away from the pacemaker. For more information consult your doctor.



The ringtone (p. 78), info tones (p. 82) and handsfree talking are reproduced through the loudspeaker. Do not hold the phone to your ear when it rings or when you have switched on the handsfree function (p. 26). Otherwise you risk serious permanent damage to your hearing.



Only use original Siemens batteries (100 % mercury-free) and – charging devices. Otherwise you risk serious damage to health and property. The battery could explode, for instance.



Small parts such as the SIM card, sealing stop, lens ring and lens cap can be dismantled and swallowed by small children. The phone must therefore be stored out of the reach of small children.



The mains voltage specified on the power supply unit (V) must not be exceeded. Otherwise the charging device may be destroyed.

To charge the battery the mains adapter must be plugged into an easily accessible mains socket. The charger can only be switched off after the battery has been charged by removing the plug from the socket.



Do not use an optical magnifier to look at the activated infrared interface [Class 1 LED product (classification as per IEC 60825-1)].



You may only open the phone to replace the battery (100 % mercury-free) or SIM card. You must not open the battery under any circumstances. All other changes to this device are strictly prohibited and will invalidate the guarantee.

**Important**

Please dispose of unwanted batteries and phones as permitted by the laws in your country.



The phone may cause interference in the vicinity of TV sets, radios and PCs.



Use only Siemens original accessories. This will avoid potential risks to health or property and ensure compliance with all relevant regulations.

Improper use will invalidate the guarantee!  
These safety instructions also apply to Siemens original accessories.

This mobile phone complies with the limit values for protecting the health of the public from the effects of exposure to electromagnetic fields when it is operated in the customary position held against the user's ear or with the display facing the user's body or held at a minimum distance of 1.5 cm from the user's body.

**Bluetooth®**

Your phone has a Bluetooth interface. This makes it possible to establish a wireless connection of your phone with a headset or a car kit, or with other Bluetooth-enabled devices.

In order to establish a secure link between the devices and to prevent a third party from having access to your phone, you should observe the following points:

- The initial connection between two devices, what is called "pairing", should take place in familiar surroundings.
- Both devices must be able to identify themselves one time by using a password/PIN. To ensure sufficient security, you should choose a 16-digit number combination for a password that would be difficult to guess (if a PIN has not been assigned).
- An automatic connection acceptance ("connection without confirmation") should only be used in exceptional cases.
- In general, only trustworthy devices should be linked in order to minimize security risks.
- The name of your phone is transmitted in a Bluetooth connection. The factory default is the "Bluetooth ID". The first time Bluetooth® is activated, or later in the Bluetooth® menu, you can change this name (**My BT name**, (p. 88)).
- If Bluetooth is not needed, this function should be deactivated.

Before using Bluetooth accessories, or a mobile phone inside a vehicle, check the vehicle user guide for any limitations on the use of these products.

# Overview of phone

## ① Call key

Dial displayed/highlighted phone numbers/names, take calls. In standby mode, show last phone numbers dialled.

## ② On/Off/End key

- Switched off: press and **hold** to switch on.
- During a conversation or in an application: press **briefly** to finish.
- In menus: press **briefly** to go back a level.  
Press and **hold** to return to standby mode.
- In standby mode: press and **hold** to switch off phone.

## ③ Joystick

- Press the joystick down vertically to start an application or function. The current function is displayed between the soft keys p. 15.

### In standby mode:

- Open main menu.
- Open user profiles.
- Open Phonebook/Addressbook.
- Open Inbox.
- Display Calendar.

### In lists, messages and menus:

- Scroll up and down.
- Back one level.

### During a call:

- Set volume.
- Call options.



## ④ Soft keys

The current functions of this key are shown in the bottom line of the displays as **Text**/symbol (e.g. ).

## ⑤ Internet

Access to the Internet portal.

### ① Integrated antenna

Do not obstruct the phone above the battery cover unnecessarily. This reduces the signal quality.

### ② Loudspeaker

### ③ + - Plus-minus key

- During a call: volume high – low.
- In menus, lists, Internet sites: scroll up and down.

In standby mode:

Press and **hold**:

+ Sound recording (press and hold).

- Display Calendar.

Press **briefly** in standby mode.

+ Play back last sound recording.

### ④ Display

### ⑤ Infrared interface (IrDA)

### ⑥ \* Δ Ringtone

- Press and **hold** in standby mode: switch acoustic signals on/off (except for alarm clock).
- Press and **hold** when incoming call is received: switch off ringtone for this call only.

### ⑦ # no Key lock

Press and **hold** in standby mode: switch key lock on/off.

### ⑧ Connection socket

For charger, headset, flash, etc.

### ⑨ Slot for RS MultiMediaCard™



















### ⑩ Car kit holder



















### ⑪ Connection for external antenna



# Display symbols

## Display symbols (selection)

	Strength of receiving signal
	Charging
	Battery charge level, e.g. 50%
	Phonebook
	Call records
	Surf & fun/ Service provider portal
	Organiser
	Messages
	Sound recorder
	Extras
	My stuff
	Setup
	All calls are diverted
	Ringer (beep) off
	Short ring (beep) only
	Ringtone only if the caller is stored in the Phonebook
	Alarm set
	Keypad locked

	Auto answer feature on
	Activated and available
	Registered
	Temporarily interrupted
	Browser offline
	Browser online
	Browser via GPRS online
	Browser no network
	IrDA activated
	IrDA transmission
	Bluetooth® activated
	Bluetooth® transmission
<b>Events (selection)</b>	
	SMS memory full
	MMS memory full
	Phone memory full
	No network access
	Missed call
	Memory assistant



**Message symbols (selection)**

Unread



Read



Draft



Sent



MMS not sent



MMS notification received



MMS notification read



MMS with DRM contents (p. 14)



E-mail forwarded




E-mail with attachment



Voice mail received

# Getting started

The phone is packaged in dismantled form and must be re-assembled prior to using for the first time.




Your phone's display is supplied with a **protective film**. Remove this film slowly before assembling the phone.

In rare cases, static discharge may cause discolouration at the edges of the display. However, this will disappear within approx. 10 minutes.


## Inserting the SIM card/ battery

The service provider supplies you with a SIM card on which all the important data for your line is stored. If the SIM card has been delivered in credit-card size, snap the smaller segment out and remove any rough edges.


- Press the grooved area ①, then push the battery cover towards the front in the direction indicated by the arrow ②.



- Place the SIM card flat in front of the slot with the contact surface facing **downwards**. Then push the SIM card in using gentle pressure ③ (ensure that the chamfered corner is in the correct position).



- Insert the battery sideways into the phone ④, then press it downwards ⑤ until it clicks into position.



- To remove the battery, pull it out with the retaining tab on the side.
- Place the cover in position and push it towards the front ⑥ until it latches into place.



#### Additional information


Please switch off your phone before removing the battery!

The phone supports 1.8 V and 3 V SIM cards. Please contact your service provider if you have an older card.


## Inserting an RS MultiMediaCard™

The RS MultiMediaCard is not included in the phone's delivery package. Please observe the manufacturer's operating instructions that come with the RS MultiMediaCard.


- To insert the RS MultiMediaCard, fold the cover out and down ①.



- Open the cover completely, then insert the RS MultiMediaCard with the contact surface facing downwards ②. Gently push the card right in until it clicks into place.



- If necessary, use the battery cover ③.




- Finally, close the cover again.
- **Before removing** the RS MultiMedia-Card, carry out the **Eject card** function in the **My stuff** options menu. This prevents any possible data loss.
- To remove the RS MultiMedia-Card, open the cover and press the card briefly (if necessary, use the battery cover). The card will pop out a little and you can remove it. Finally, close the cover again.

## Charging the battery

### Charging procedure

The battery is not fully charged when delivered. Plug the charger cable into the bottom of the phone, plug the power supply unit into a mains power socket and charge for at least **two hours**.



Display during charging.

### Charging time

An empty battery is fully charged after about 2 hours. Charging is only possible within a temperature range of 5 °C to 45 °C. If the temperature rises/falls 5 °C above/below this, the charge symbol flashes a warning. The mains voltage specified on the power supply unit must not be exceeded.

## Operating times

The operating time depends upon the respective conditions of use. Extreme temperatures considerably reduce the phone's standby time. Avoid placing the phone in the sun or on a heater.

Talktime: 100 to 300 minutes  
Standby time: 60 to 250 hours

## Charge icon not visible

If the battery has been discharged fully, the charge icon is not immediately visible when the power supply is plugged in. It will appear after up to two hours. In this case, the battery is fully charged after 3 to 4 hours.

**Only use the plug-in power supply unit included in delivery!**

## Display while in service

Charge level display during operation (empty – full):



A beep sounds when the battery is nearly empty. The charge level of the battery is only displayed correctly after an uninterrupted charging/discharging cycle. Therefore **do not remove the battery unnecessarily**, and where possible, **do not end the charging process prematurely**.

### Additional information

The power supply unit heats up when used for long periods. This is normal and not dangerous.

If the battery is removed for longer than 30 seconds, the clock must be reset.

# Switching on/off, PIN entry

## Switching phone on/off



Press and **hold** the On/Off/End key.

## Entering the PIN

The SIM card can be protected with a 4 to 8-digit PIN.



Enter the PIN using the number keys. The characters \*\*\*\* appear to ensure nobody can read your PIN on the display. Correct with **⏪**.

**OK**

Confirm. Logging on to the network will take a few seconds.

### Additional information

Change PIN.....p. 18

Clear SIM card barring .....p. 19

## Emergency number (SOS)

**Only to be used in real emergencies!**

By pressing the **SOS** soft key you can make an emergency call on any network **without** a SIM card and without entering a PIN (not available in all countries).

## Switching your phone on for the first time

### Time/date

Set the clock correctly on a one-off basis when getting started.



Press this key, then select **Change**.



First enter the date (day/month/year), then the time (24 hours, including seconds).



Press. The time and date are updated.

### Time zones

Set the time zone for your area.



Select the city in the desired time zone from the list ...

**Set**

... and set it.

## Copying SIM addresses

The first time the SIM card is inserted, the entries on it can be copied to the Addressbook. Please **do not interrupt this procedure**. During this time, **do not accept incoming calls**. Follow the instructions in the display.

You can also copy data from the SIM card at a later time (p. 37).

# General instructions

## Standby mode

The phone is in **standby mode** and is **ready for use** when the name of the service provider appears on the display.



Press and **hold** the On/Off/End key to return to standby mode from any situation.

## Signal strength



Strong receiving signal.



A weak signal reduces the voice quality, can cause the connection to be lost, and consumes more current. Change your location.

## Digital Rights Mgmt. (DRM)

Remember that your phone has Digital Rights Management. The use of downloaded pictures, sounds or applications can be restricted by the suppliers, e.g. copy protection, use for a limited period of time only, the number of times it can be used etc. (see also p. 72).

## Main menu

The main menu is displayed graphically with symbols:



Call main menu up from standby mode.



Select the application symbols.



Start an application.

## Main menu options

**Options** Open menu.



Different functions are available depending on the context.

<b>Big letters</b>	Select one of two font sizes.
<b>Illumination</b>	Set display illumination to brighter/darker.
<b>Eject card</b>	Allows the RS MultiMediaCard to be removed without loss of data.
<b>Help</b>	Display a help text.


## User guide



### Menu controls


The steps needed to reach a function are shown in a **condensed form** in the user guide, e.g. to display record of missed calls in condensed form:

 →  → Calls missed


This comprises the following steps:

 Open main menu.

 Select .

 Confirm.

 Select **Calls missed**.

 Confirm.

## Symbols

The following symbols are used to explain operation:



Enter numbers or letters.



On/Off/End key



Call key



Soft keys



Displays a soft-key function.



Press vertically down on the joystick (to call up the menu, for example).




Press the joystick in the direction indicated.




Function dependent on service provider. May require special registration.

### Press joystick

The symbol in the centre of the lower line of the display shows the current function when the joystick is pressed down vertically, e.g.

 Display menu

 Call, accept call


 OK



# Standard functions

## Option menus



Functions which appear repeatedly in the options menu are listed here.

<b>Options</b>	Open menu.
<b>Edit</b>	Open the entry to edit.
<b>View</b>	Display entry.
<b>Delete/ Delete all</b>	Delete entry/delete all entries after confirmation.
<b>New entry</b>	Create new entry.
<b>Send...</b>	Select transmission service and medium for sending or printing e.g. IrDA or Bluetooth.
<b>Reply/ Reply to all</b>	The sender becomes the recipient, "Re:" is placed in front of the subject matter and the received text is transferred to the new message.
<b>Save</b>	Save entry.
<b>Save to</b> 	Save recipients in the current address directory.
<b>Sort</b>	Set sort criteria (alphabetical order, type, time).

<b>Text input</b> (p. 20)	<b>T9 preferred:</b> Activate/deactivate T9 input. <b>Input language:</b> Select language for text.
<b>Rename</b>	Rename selected entry.
<b>Capacity</b>	Display memory capacity.
<b>Attributes</b>	Display properties of the highlighted object.
<b>Help</b>	Display help text.

## Highlighting mode

With some applications (e.g. Phonebook/Addressbook), you can highlight one or more entries in a list in order to carry out a function jointly.

- Options** Open menu.
- Mark** Activate highlighting mode.
-  Select entry/entries.
-  Highlight or remove highlighting.
- Mark** The current entry is highlighted.
- Unmark** Remove highlighting from the current entry.





Additional highlighting functions:

<b>Mark all</b>	Highlight all entries.
<b>Unmark all</b>	Delete highlighting on all highlighted entries.
<b>Delete marked</b>	All highlighted entries are deleted.

## Menu speed dialling

All menu functions are numbered internally. A function may be selected directly by entering these numbers in sequence.

E.g., to write new SMS (from standby mode):

-  Press to display the main menu. Then press
-  for **Messages**, then
-  for **Create new**, then
-  for **SMS**.

# Security

The phone and SIM card are protected against misuse by several security codes.

**Keep these security codes in a safe place where you can access them again if required.**

## PIN codes

PIN	Protects your SIM card (Personal Identification Number).
PIN2	This is needed to set the charge detail display and to access additional functions on special SIM cards.
PUK PUK2	Key code. Used to unlock SIM cards after the wrong PIN has been entered repeatedly.
Phone code	Protects your phone. Must be entered at the first security setting.



## PIN control

The PIN is usually requested each time the phone is switched on. You can deactivate this feature but you risk unauthorised use of the phone. Some service providers do not permit deactivating the control.

**Change** Press.



Enter PIN.



Confirm input.

## Change PIN

You can change the PIN to any 4 to 8-digit number you find easier to remember.

**Select** Press.



Enter **current** PIN.



Press.



Enter **new** PIN.



Repeat **new** PIN.



## Change PIN2

(Display only if PIN2 is available).  
Proceed as for **Change PIN**.

## Chg.phonecode

(Change phone code)

You define the phone code (4 to 8 digits) when you call up a phone-code protected function for the first time (e.g. **Direct call**, p. 28). It is then valid for all phone-code protected functions.

Following the third unsuccessful attempt, access to the phone code and the functions that use it is denied. If this occurs, contact Siemens Service (p. 120).

## Clearing SIM card barring

If the PIN is entered incorrectly three times, the SIM card is barred. Enter the PUK (MASTER PIN) provided by your service provider with the SIMcard in accordance with the instructions. If the PUK (MASTER PIN) has been lost, please contact your service provider.

## Preventing accidental activation

Even if PIN control is deactivated (p. 18) confirmation is required to switch on the phone.

This prevents accidental activation of the phone, e.g. when you are carrying it in a bag or when you are travelling in an aircraft.



Press and **hold**.



Press.  
The phone switches on.



Press this key or take no action. The phone does not switch on.

# Text entry

## Text entry without T9

Press the number key repeatedly until the required character appears. After a brief interval the cursor will advance. Example:



Press **once briefly** to write the letter **a**, twice to write **b** etc.

**Press and hold** to write the number.

Ä, ä, 1-9

Unusual characters and numbers are displayed after the relevant letters.



**Press briefly** to delete the letter before the cursor.  
**Press and hold** to erase the whole word.



Move the cursor (forwards/back).



**Press briefly:** Swap between *abc*, *Abc*, *T9abc*, *T9Abc*, 12. Status shown in top line of display.

**Press and hold:** all input-variants are displayed.



**Press briefly:** special characters are shown.

**Press and hold:** open input menu.



**Press once/repeatedly:**

.,?!' "0+-()@/!:\_

**Press and hold:** writes 0.



Writes blank. Press twice = line break.

## Special characters



Press **briefly**. The symbols chart is displayed:

1)	¿	¡	_	;	.	,	?	!
+	-	"	'	:	*	/	(	)
¤	¥	\$	£	€	@	\	&	#
[	]	{	}	%	~	<	=	>
	^	`	§	Γ	Δ	Θ	Λ	≡
Π	Σ	Φ	Ψ	Ω				

1) Line break



Navigate to characters.



Confirm.

## Input menu

For text input:



Press and **hold**. The input menu is displayed:

Text format (SMS only)  
Input language  
Mark  
Copy/Insert

## Text entry with T9

“T9” deduces the correct word from the individual key entries by making comparisons with an extensive dictionary.

### Activating, deactivating T9

**Options** Open text menu.

**T9 input** Select.

**Change** Activate T9.

### Selecting input language

Select the language in which you want to compose your message.

**Options** Open text menu.

**Input language**

Select.



Select language.


**Select** Confirm. The new language is set. Languages with T9 support are marked with the T9 symbol.

### Writing with T9

The display changes as you proceed.

**It is therefore best if you finish a word without looking at the display.**

Simply press the keys **once** where the relevant letter is located. For “hotel”, for example:



Press **briefly** for T9Abc then



A blank ends a word.

Do not use special characters such as Ä. Use standard characters instead, e.g. A; T9 will do the rest for you.

T9® Text Input is licensed under one or more of the following:

U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945 928 and 6,011,554;

Canadian Pat. No. 1,331,057;

United Kingdom Pat. No. 2238414B;

Hong Kong Standard Pat. No. HK0940329;

Republic of Singapore Pat. No. 51383;

Euro.Pat. No. 0 842 463 (96927260.8)


DE/DK, FI, FR, IT, NL, PT, ES, SE, GB;


and additional patents are pending worldwide.

## T9 word suggestions

If several options are found in the dictionary for a key sequence (a word), the most probable is displayed first. If the word you want has not been recognised, the next suggestion from T9 may be correct.

The word must be shown **highlighted**. Then press

 Press. The displayed word is replaced with a different word. If this word is also incorrect, press again.

 Press. Repeat until the correct word is displayed.


If the word you want is not in the dictionary, it can also be written without T9.


To add a word to the dictionary:


**Spell** Select.

The last suggestion is deleted and the word may now be entered without T9 support. Press **Save** to add it automatically to the dictionary.

## Correcting a word


 Move left or right, word by word, until the required word is **highlighted**.

 Scroll through the T9 word suggestions again.


 Deletes the character to the left of the cursor **and** displays a new possible word.


### Additional information

Within a "T9 word", individual letters may not be edited without first removing the T9 status. In most cases it is better to rewrite the complete word.


 Set a full stop. The word is concluded if it is followed by a space. Within a word, a full stop represents an apostrophe or hyphen:

e.g. **provider.s** = provider's.

 Moving the cursor to the right ends the word.

 **Press briefly:** switch between: abc, Abc, T9abc, T9Abc, 123. Status shown in top line of display.

**Press and hold:** all input variants are displayed.

 **Press briefly:** select special characters (p. 20).

**Press and hold:** opens input menu (p. 21).

## Text modules

Text modules can be stored in the phone for adding to your messages (SMS, MMS, e-mail).

### Writing text modules



<New entry>

Select.



Write text.

**Options**

Open menu and select **Save**. Accept the suggested name or allocate a new one.



Save.

### Using text modules



Write message (SMS, MMS, e-mail).

**Options**

Open text menu.

Insert...

Select.



Select **Text module**.



Select text module from the list.

**Select**

Confirm. The text module is displayed.



Confirm. The text module is inserted in the message to the right of the cursor.




# Calling

## Dialling with number keys

The phone must be switched on (standby mode).



Enter the number (always with area/international dialling code).

 A **short** press clears the last digit, a **long** press clears the entire phone number.



Press the Call key. The displayed phone number is dialled.

## Ending a call



Press the End key **briefly**. Press this key even if the person on the other end of the line has hung up first.

## Setting the volume

It is only possible to adjust the volume during a call.



With the joystick.

Or



With the plus/minus key.

If a car kit is used, its volume setting will not affect the usual setting on the phone.

## Redialling previous numbers

To redial the phone number **last** called:



Press the Call key **twice**.

To redial other numbers that were dialled previously:



Press the Call key once.



Pick out the phone number from the list, then to dial press the ...



... key.


## If the number is busy

If the called number is busy or cannot be reached because of network problems several options are available (depending on the service provider). An incoming call or any other use of the phone interrupts these functions.

Either

### Auto. redial

**Auto dial** The phone number is automatically dialed ten times at increasing time intervals. End with:

 End key.

Or

### Call back


**Call back** Your phone rings when the busy number is free. Press the Call key to dial the number.




## Reminder

**Prompt** A beep reminds you to redial the displayed phone number after 15 minutes.


### Additional information

 Store phone number in the Addressbook/Phonebook.

**Handsfr.** Switch on Handsfree (playback from loudspeaker).

 Press and hold to switch microphone off.

### International dialling codes

 Press and **hold** until a "+" is displayed.

**Country** Press and select country.

### Phone number memo

You can enter a phone number during the call. The person to whom you are speaking can hear these entries. When the connection has ended you can save or dial the phone number.

## Accepting a call

The phone must be switched on. An incoming call will interrupt any other use of the phone.



Press.

Or



Press.

A phone number transmitted by the network plus the corresponding name (possibly with a picture) are displayed if they are stored in the Phonebook/Addressbook (p. 33).

## Rejecting a call

**Reject** Press.

Or



Press **briefly**.

### Warning!

Please make sure you have accepted the call before holding the phone to your ear. This will avoid damage to your hearing from loud ringtones.

### Additional information



Press and **hold** to switch off the ringtone and silent alert.



Missed call display.

## Handsfree

You can put the phone down during a call. You can then hear the caller via the loudspeaker.

**Handsf.** Activate handsfree talking.



Switch on.



Regulate the volume with the joystick or the plus/minus key.

**Handsf.** Deactivate.

### Warning!

Always switch off "handsfree talking" before holding the phone to your ear! Otherwise, you will damage your hearing!

## Swapping between 2 calls



### Establish a second connection

You can call another number during a call.



Open call menu.

**Hold**

The current call is put on hold.



Now dial the new phone number or select

Open the call menu, then select **Default book**, and then select the phone number.

When the new connection is established:

**Swap** Swap between calls.

## Incoming calls during a call

You may need to register for this service with your service provider and set your phone accordingly (p. 80). During a call, you may be advised that there is another call waiting. You will hear a special tone during the call. You have the following options:

- **Accept the waiting call in addition to the first**

**Swap** Accept the waiting call, putting the current call on hold to do so.

Always proceed as above to swap between the two calls.

- **Reject the waiting call**

**Reject** Press.

Or

**Divert** The waiting call is diverted, for example, to the mailbox.

- **Accept the waiting call and end the current call**



End the current call.



Accept new call.

## Ending call(s)



Press the End key.

After the **Return to held call?** display, you have the following selection:

**Yes** You accept the call on hold.

**No** You end the second call too.

## Conference



Call up to 5 parties one by one and link them together in a multiparty call. Some of the functions described may not be supported by your service provider or may have to be enabled specially.

A connection has already been established:



Open the call menu and select **Hold**. The current connection is maintained.



Now dial a new number. When the new connection is established ...



... Open the call menu and select **Conference**. The held call is joined.

Repeat procedure until all participants are linked together (up to 5 participants).

## Ending




All calls in the conference are ended when you press the End key.


## Call options

The following functions are only available during a call:



Press.

Hold	Hold current call.
Microphone on	If switched off, the person on the other end of the line cannot hear you (muting). Also:  Press and hold.
Handsfree	Playback through the loudspeaker.
Volume	Adjust handset volume.
Default book	Phonebook/Addressbook.
Conference	(p. 27)
Time/charge	Display talktime that has elapsed so far and (if set) charges incurred during the connection (p. 40).
Send DTMF	Enter tone sequences (numbers) for remote inquiries to an answering machine.

**Call transfer**  Connect the original call to a second call. For you, both calls are now ended.

**Main menu** Access to the main menu.

**Call status** List all held and active calls (e.g. participants in a conference).

## Direct call

If this is active, only **one** number can be dialled.

### Switch on



→  Security  
→ Direct call



Confirm selection.



Enter phone code.

When first prompted you define and enter the phone code (4–8 digits).



Confirm selection.

**Please do not forget this code (p. 18)!**



Select phone number from the Phonebook/Addressbook or enter it.



Confirm.

## Apply

**Carol**

To dial the phone number (e.g. Carol's phone number), press and **hold** the right soft key.

## Switch off



Press and **hold**.



Enter phone code.



Confirm input.

## Tone sequences (DTMF)

You can, for example, enter control codes (numbers) for remote access to an automatic answering machine **while another connection exists**. These entries are transmitted directly as DTMF codes (control codes).



Open the call menu.

### Send DTMF

Select.

## Using the Phonebook/ Addressbook

Store phone numbers **and** control codes (DTMF codes) in the Phonebook/Addressbook in the same way as a normal entry.



Enter phone number.



Press until a "+" appears in the display (wait for the connection to be established).



Enter DTMF codes (numbers).



If necessary, wait again for three seconds at a time for the receiver to process the entries safely.



Enter a name.

**Save**

Store entry.

You may also store just the DTMF codes (numbers) and then send them during the call.

# My items

Set your phone as you wish for the following items:

## **Ringtones (p. 78)**

Assign individual ringtones to caller groups or special dates.

## **Pictures (p. 113)**

Assign individual pictures or photos to your Addressbook entries.

## **Animations (p. 77)**

Choose a start up and shut down animation as well as a personal greeting.

## **Themes (p. 75)**

Load a completely new visual presentation onto your phone.

## **Screensaver (p. 76)**

Choose an analogue or digital clock, or a personal picture.

## **(Operator) Logo (p. 76)**

Choose an individual picture (to be displayed in standby mode)

## **Wallpaper (p. 76)**

Choose your own permanent background image.

## **Colour skin (p. 76)**

Select a colour skin for the user interface.

## **Applications (p. 71)**

Download your own applications from the Internet.

## **Where do I get what?**

You can purchase additional ringtones, logos, animations and Java applications from your service provider or directly from Siemens.

## **Service provider portal**

Depending on your service provider, you will find direct access to his portal on your telephone via menu items or bookmarks. Please contact your service provider for more information on these services.

## **Siemens Mobile Portal**

You will find additional ringtones, logos, animations and screensavers as well as more applications, games and services on the Internet at:

**[www.siemens.com/mobilephones](http://www.siemens.com/mobilephones)**

or you can download them directly from the Internet:

**[wap.siemens.com](http://wap.siemens.com)**

You will also find a service for saving data here as well as a list of the countries in which these services are available.

## **My menu**


Create your own menu (p. 96) with frequently used functions, phone numbers or Internet pages.

# Default book

 →  → Select function.

## Show entries

The entries in the default book (Addressbook or Phonebook) are shown.

 Select a name with the first letter and/or scroll.

## New entry

Create new entry.


**Addressbook** (see also p. 32)

**Phonebook** (see also p. 36)

## Default book

You can set which directory you prefer to use.

The selected default book is opened in standby mode with the joystick.

 Open Phonebook or Addressbook

## Addressbook


A lot of data can be saved in the Addressbook for each entry and additional functions (e.g., **Birth day:**, **Picture:**, **Inst. message**) can be used.

## Phonebook

The Phonebook is located on the SIM card. Only one phone number can be entered per entry. The Phonebook on the SIM card can easily be transferred into a different phone.

## Business card


Create your own business card to send to a different GSM-phone. If no business card has been created yet, you will be asked for your input.

 Move from field to field to enter your details.

**Save** Press.

### Additional information

The content of the business card corresponds to international standards (vCard).

 Copy numbers from Addressbook/Phonebook.

## Groups

See p. 35.

## <Info numbers>

See p. 38.







# Addressbook

The Addressbook can store up to 1,000 entries, each with a variety of phone and fax numbers as well as additional address details. These entries are managed in the phone memory separately from those in the Phonebook. However, you can exchange data between the Addressbook and the Phonebook on the SIM card.

## New entry

The Addressbook is set as standard:

-  Open Addressbook (in standby mode).
  -  Display input fields.
  -  Select required input fields.
  -  Fill in input fields. The maximum number of characters available is shown at the top of the display.
- At least one name must be entered. Always enter phone number with dialling code.

## Possible input fields

Last name:	URL:
First name:	Inst. message >>
Phone number:	Group:
Phone no./office:	Company:
Phone no./mobile:	Address: >>
Fax:	Birthday: >>
Fax 2:	Picture:
E-mail:	
E-mail 2:	All fields

## Additional information

- Group:** Allocation to a group (p. 35).
- Address:** Extension to enter the complete address:  
**Street:, Post code:, City:, Country:**

## Com. services

- Information if the entry is being used as an Inst. Message contact (p. 60):  
**Nickname:, WV user ID:, ICQ number:, AIM screen name:**

**Birthday:** After activation, the date of birth is entered.

**Reminder:** The phone reminds you at the time you set one day before the birthday.

**Picture:** Assign a picture to the entry. This is displayed when you are called by a corresponding phone number.

#### All fields/Reduced fields

Displays the number of input fields.

**Save** Save the entry.

#### Additional information



Temporary switch to Phonebook.

#### Synchronisation

With the mobile phone manager (p. 115) you can synchronise your Addressbook with Outlook®, Lotus Notes™ and other Siemens phones.

Using **Remote syncr.** you can synchronise your mobile with an organiser stored on the Internet (see also p. 109).

## Displaying/finding entry



Open Addressbook (in standby mode).



Select a name with the first letter and/or scroll.



Display.








## Display options

### Options




The options menu only ever offers the functions for the currently selected input field.

<b>Move to ...</b>	Assign current entry or highlighted entries to a group.
<b>View</b>	Display an assigned picture.
<b>Copy to SIM</b>	Copy name and <b>one</b> phone number to the SIM card (Phonebook).
<b>New SMS, New MMS, New e-mail</b>	Create a message with the selected entry.
<b>Browser</b>	Start browser and visit URL.
<b>Inst. Message</b>	Start a dialogue with the selected entry (p. 60).
(For standard functions see p. 16)	



## Changing an entry

-  Open Addressbook (in standby mode).
-  Select required entry.
-  Press.
-  Select input field.
-  Open entry.
-  Make changes.
-  Save.

## Calling an entry

-  Open Addressbook (in standby mode).
-  Select a name with the first letter and/or scroll.
-  The number is dialed.

If there are several numbers in the Addressbook entry, these are offered for selection.

-  Select phone number.
-  The number is dialed.

## Addressbook options




Depending on the actual situation, different functions will be offered. These functions can be applied to the entry currently selected as well as to multiple selected entries:

**Options** Open menu.

<b>Move to ...</b>	Assign current or highlighted entries to a group.
<b>Copy to SIM</b>	Copy name and phone number to the SIM card (Phonebook).
<b>Filter</b>	Only those entries which match the filter criteria are displayed.
<b>Import</b>	Set up readiness to receive for a Phonebook entry via IrDA (p. 85) or SMS (p. 42).
<b>Sort</b>	Specify sorting criteria for output of the Addressbook entries.
<b>Search</b>	Enter search term.
(For standard functions see p. 16)	

## Groups

Nine groups are specified in your phone to enable you to arrange your Addressbook entries clearly. You can rename seven groups.

-  Open Addressbook (in standby mode).
- <Groups>** Select (the number of entries is listed after the group name).
-  Select group.
-  List entries in the group for viewing and editing.

## Groups menu

**Options** Open menu.

<b>Rename group</b>	Change name of group.
<b>Group symbol</b>	Assign a symbol to a group. The symbol will then appear in the display when one of the group members calls.







### Additional information

**No group:** Contains all Addressbook entries that do not belong to a group (name cannot be changed).

**Received:** Contains Addressbook entries received by IrDA (p. 85), Bluetooth (p. 86) or SMS (p. 42) (name cannot be changed).

## Ringtone for group

Assign a ringtone to a group that plays when one of its members calls you.





-   → Ringtones  
→ Group calls
-  Select group.
-  Confirm. If a ringtone has already been set, it will be played. Otherwise, the ringtone list will be displayed and you can select one.
-  If necessary, select a ringtone.
-  Confirm.

# Phonebook

Entries in the Phonebook (on the SIM card) are managed separately from those in the Addressbook. You can, however, exchange data between the Phonebook and the Addressbook.

## New entry

If the Phonebook has been selected as the default book:

-  Open Phonebook (in standby mode).
- <New entry>  
Select.
-  Display input fields.
-  Select input field.
-  Fill in input fields. The maximum number of characters available is shown at the top of the display.

### Number:

Always enter phone number with dialling code. An entry will not be saved without a phone number.

### Name:

Enter first and/or last names.

### Group:

Default: **No group**

Important phone numbers can be put in one group (**VIP**). This group is independent from groups in the Addressbook.

### Location:

Default: **SIM**

Special SIM cards can save phone numbers in a protected area (**Protected SIM**) (PIN2 required).

### Record number:

Each entry is automatically assigned a record number. You can also dial using the record number.

### Save

Press to store the new entry.

### Additional information



Temporary switch to Addressbook.

**Country** International dialling code.....p. 25  
 Functions concerning Text entry .....p. 20

## Calling (searching for an entry)



Open Phonebook.



Select a name with the first letter and/or scroll.



Phone number is dialed.

## Calling using record no.

A record number is automatically assigned to every new entry in the Phonebook.



Enter record number.



Press.



Press.

## Changing an entry



Select entry in Phonebook.



Press.



Select desired input field.



Make changes.



Press.

## Phonebook options

The following functions are available, depending on the current situation.

**Options** Open menu.

**Copy into** Copy all highlighted entries to the Addressbook.

**Copy all to** Copy all entries to the Addressbook.

**Delete all** The whole Phonebook is deleted (PIN-protected).

**Import** Set up readiness to receive for a Phonebook entry via IrDA (p. 85) or SMS (p. 42).

(For standard functions see p. 16)

## <Special books>



Open Phonebook  
(in standby mode).

### <Special books>

Select.

## <Own numbers>

Enter "own" phone numbers in Phonebook (e.g., fax) for information. These numbers can be changed, deleted and also sent as an SMS message.

## <VIP numbers>

Display the phone numbers saved in the VIP group.

## <SIM phonebook>

Entries stored in the Phonebook on the SIM card can also be used on other GSM phones.

## <Protected SIM>

On special SIM cards, phone numbers can be stored in a protected location. PIN2 is required for editing.



## <Service nos.>/<Info numbers>

There might be phone numbers saved in your Phonebook that have been provided by your service provider. They may be used to call local or national information services or to use services offered by your service provider.

### Completing phone numbers in the Phonebook

Digits may be replaced by a "?" when phone numbers are entered in the Phonebook:



Press and **hold**.

These wildcards must be replaced with numbers before dialling (e.g., with the extension numbers in a phone system).

To make a call, select the phone number from the Phonebook.



Press.



Replace "?" with numbers.



The phone number is dialled.

# Call records

The phone number of a caller is displayed if

- the caller has switched off the **Hide ID** function and
- the network supports the “Caller Identity” function.

Alternatively, a caller’s name is displayed if it is stored in the Phonebook/Addressbook.

Your phone stores the phone numbers of calls for convenient redialling.



Select record.



Open call record.



Select phone number.



Dial phone number.

Or

**View**

Display information on the phone number.

Up to 500 entries are stored in the records:

## Calls missed



The phone numbers of calls that you have received but not answered are stored for call back purposes.



Symbol for missed call (in standby mode). Press the soft key beneath the symbol to bring up the **Inbox** (p. 41).

## Calls received

Accepted calls are listed.

## Calls dialled

Access to the last numbers you have dialled.



Fast access in standby mode.

## Delete records

The records are deleted.

## Records menu

The records menu can be called up if an entry is highlighted.

**Options**

Open menu.

**Copy into**  /  
**Copy to SIM**

Copy the currently selected phone number into the preferred directory.

(For standard functions see p. 16)



## Durat/charges

You can display the charges and duration during a call. You can set a unit limit for outgoing calls.



Select

Last call

All outg. calls

All incoming

Remain. units

Charge sett.



Scroll through the display.



Open item.

**Reset**

Reset the currently selected setting.

### Charge sett.



Open menu.

### Currency

Enter desired currency.

### Personal rate

(PIN2 prompt)

Enter the currency as well as the charge per unit and time.

### Account limit

(PIN2 prompt)

Special SIM cards allow you or the service provider to define a credit limit or a period after which the phone is barred for outgoing calls.

**Edit**

Press.



Enter PIN2.

Account limit

Switch on.



Enter number of units.

**OK**

Confirm.

Then confirm the credit or reset the counter. The status display for prepaid cards may vary depending on the service provider.

### Auto display

Call duration and charges are displayed automatically.

# Inbox

The inbox folder offers immediate access to the messages currently received. This means that you no longer have to look through all inbox folders for the various message types. The entries are marked with a symbol to indicate their type and status. You will find an overview of the symbols on p. 7.

To call up the inbox folder, e.g. if you have received a new SMS:



Press the soft key beneath the symbol.

**Or**



Press in standby mode.

In the inbox folder you will find the following message types:

**SMS, MMS, E-mail**

## System messages

Notification about **MMS, Missed alarm, Missed appts., Calls missed, WAP push, Voice message**

## Data objects

**Ringtones, Pictures and Video, calendar entries, Notes and Business card**



When you open an entry, the relevant application also starts.

After a set period, entries which have already been read and opened are only displayed in the message-related incoming lists (see **Setup** in the options menu).

## Inbox options

**Options** Open menu.

**Rec. e-mails** Select set account and send all e-mails.

**Setup** If entries have been read, remove them from the **Inbox**:  
**Daily, Never, Immediately**  
 If **Daily** has been selected, specify the time.

(For standard functions see p. 16)

### Additional information

Where applicable you will receive WAP push messages from special servers. These may contain information from the service provider or important data such as how to set up a connection profile.

**Accept** For example, start setting up a connection profile automatically.

# SMS

You can use your phone to transmit and receive very long messages (up to 760 characters). They are automatically composed of several “normal” SMS messages (note higher charges).

Additionally, you can insert pictures and sounds in an SMS.

## Writing/sending



→ → Create new  
→ SMS text



Enter text.

You will find information on writing texts with and without T9 in the chapter “Text entry” (p. 20).

The following is displayed in the display line: text entry status, number of SMS required, number of characters still available.



Start sending procedure.



Select phone number from the Phonebook/Addressbook or enter it.

**Group** If necessary, select a group.



Confirm. The SMS is transmitted to the service centre to be sent and saved in the **Sentbox** list.

## Text options

<b>Options</b>	Open menu.
<b>Save</b>	Save composed text in draft list.
<b>Picture&amp; sound</b>	Add pictures, animations and sounds to message (see following text).
<b>Insert...</b>	Insert <b>Text module</b> (p. 23), <b>Bookmarks</b> , <b>From</b> (Addressbook/Phonebook).
<b>Format</b>	Font size: <b>Small font</b> , <b>Medium font</b> , <b>Large font</b> <b>Underline</b> <b>Alignment: Default alignm., Left, Centre, Right</b> <b>Mark</b> (highlight text with the joystick)
<b>Delete text</b>	Delete the whole text.
<b>Send with...</b>	Select SMS profile so the SMS can be sent.

(For standard functions see p. 16)

## Picture&sound

Send pictures and sounds with or without accompanying text.

Remember that these may be protected (DRM, p. 14).

With the text input field open:

### Options

Open menu.



Select **Picture&sound**.

The menu contains:

**Fix animations**

**Fix sounds**

**Own animat.**

**Own pictures**

**Own sounds**



Select list.



Confirm. The first entry of the selected section is displayed.



Scroll to entry required.

For **Fix animations**/**Fix sounds**:



The selection is added to the SMS.

For **Own animat./Own pictures/Own sounds**:



The selection is displayed/played back.



The selection is added to the SMS.

The pictures which have been added are displayed. Sounds are displayed in the form of "wildcards".

## SMS to group

You can send an SMS message as a "circular" to a recipient group.



Start sending process.

### Group

The Addressbook is opened.

<Groups>

The list of groups is displayed.



Select group.



Open group and highlight all/individual entries.



Transmission is started after a security prompt.

## Reading




Arrival of a new SMS announced in the display. Open Inbox (p. 41) with the soft key beneath it.



Reading the SMS.



Scroll through message line by line.



## Replying

You can answer the SMS that is currently open immediately. The newly added text is placed above the received text.



Reply immediately.

## Reply options

**Reply** Open reply menu.

<b>Write message</b>	Create a new reply text.
<b>Edit</b>	Edit received SMS or add new text.
<b>Answer is YES</b>	Add Answer is YES to the SMS.
<b>Answer is NO</b>	Add Answer is NO to the SMS.
<b>Please call back, Delay, Thank you</b>	Add a standard text as a reply to an SMS.

## Read options

**Options** Open reply menu.

<b>Reply</b>	See "Reply options" above.
<b>Picture&amp;sound</b>	Save picture/sound contained in the SMS.
<b>Text zoom</b>	Enlarge or reduce text display.
<b>Archive</b>	Move SMS message to archive.

(For standard functions see p. 16)

## Lists

All SMS messages are archived in different lists, according to their status. (For overview of message symbols, see p. 7):

### Inbox



The list of received SMS messages is displayed.

### Draft



The list of not yet transmitted SMS messages is displayed.

### Unsent



The list of concatenated SMS messages not yet sent is displayed. Transmission can be restarted.

### Sentbox



The list of sent SMS messages is displayed.

### SMS archive



The list of SMS messages stored in the phone is displayed.

## List options

Different functions are offered depending on the list.

**Options** Open menu.

Send	Send or forward entry.
Send with...	Select an SMS profile for transmission.
Archive	Move SMS message to archive.

(For standard functions see p. 16)

## Setting

### SMS signature



You can enter a “signature” with up to 16 characters. This signature will then be attached to each SMS except for a **Reply** and when changes are made to an existing SMS.

### SMS profiles



Up to 5 SMS profiles can be set. These define the transmission characteristics of an SMS. The pre-setting depends on the SIM card inserted.

#### Activating a profile



Select profile.



Activate.

#### Setting a profile



Select profile.

**Edit** Open to edit the profile.

**Service centre** Enter the phone numbers for the service centre as provided by the service provider.

**Recipient** Enter a standard recipient for the profile.

**Message type**

- **Manual:** Inquiry for all messages.
- **Standard text:** Normal SMS message.
- **Fax:** Transmission via SMS.
- **E-mail:** Transmission via SMS.
- **New:** You may need to obtain the required code number from your service provider.

**Validity period** Period in which the service centre is to try to deliver the message:

Manual, 1 hour, 3 hours, 6 hours, 1 day, 1 week, Maximum\*

\* Maximum period that the service provider permits.

**Status report** Receive confirmation of successful/failed transmission of a message. This service may be subject to a charge.

**Direct reply** If activated, the reply to your SMS message is handled via your service centre (for information, please contact your service provider).

**SMS via GPRS** Send SMS automatically via GPRS (p. 85).

**Save aft. send** Sent SMS messages are saved in the **Sentbox** list.

## More information on SMS


### SMS status report

If the message cannot be transmitted to the service centre you are offered the chance to repeat the transmission. If this also fails, contact your service provider.


The **Message sent!** message only indicates transmission to the service centre. This will then attempt to relay the message within a certain period.

See also **Validity period** (p. 46).

### Phone number in SMS

Phone numbers displayed **highlighted** in the text can be dialled () or saved in the Phonebook/Addressbook.

### Downloading ringtones and logos

You can receive links for downloading ringtones, logos, screensavers, animations and information about applications with an SMS. Please highlight this link and, by pressing the Call key , start the download. Please check that the dial-in access is configured (p. 88).

Remember that these may be protected (DRM, p. 14).

### **SIM memory full**

If the message symbol flashes the SIM memory is full. **No** more SMS messages can be received. You need to delete messages or move them to the RS MultiMediaCard.



# MMS

The **Multimedia Messaging Service** enables you to send texts, pictures/ videos and sounds in a combined message to another mobile phone or to an e-mail address. All elements of an MMS message are merged to form a “slide show”.

Depending on your phone's settings, you will receive either the complete message automatically or notification that an MMS has been saved in the network, giving sender and size details. You may then download it to your phone to read it.

Ask your service provider whether this service is available. You may need to register for this service separately.

## Creating an MMS



→ Create new → MMS

An MMS consists of the address header and the content.

An MMS may consist of a series of pages. Each page may contain a text, a picture/video and a sound.

Remember that pictures and sounds may be protected (DRM, p. 14).

Write **texts** with the help of T9 (p. 20).

**Pictures** and **videos** can be downloaded from **My stuff** (p. 113).

**Sounds** can be recorded with the sound recorder and/or loaded from **My stuff** (p. 113).

First select an object for processing to be added to the first page of the MMS:

### Pictures/videos

Limits on picture size can be set in the user settings.



Display picture/ video functions:

#### Insert picture

Open list to select a picture.

#### Insert video

Open list to select a video.

#### Delete item

Delete inserted picture/video.

#### Save picture/Save video

Save picture/video for use later on.

#### Rights details

Display properties, including any user right restrictions (p. 14).

## Sounds

**SOUND** Select.



Display sound functions:

### Insert sound

Open list to select a sound.

### Record

Activate sound recording to record sounds (p. 111).



Also possible.

### Open

Play back sound.

### Delete item

Delete inserted sound.

### Save sound

Save sound to use later on.

### Rights details

Display properties, including any user right restrictions (p. 14).

## Text

**TEXT** Select and write the text.



The text functions are displayed (see also p. 20):

### Insert

Choose any of the following for insertion: **Text module**, **Bookmark**, **From** A small icon of a document or page, used here to represent a source for text insertion.

### Delete text

Delete text on current page.

### Save text

Save text on the page as a text module.

### T9 setup

T9 settings:

T9 preferred, Input language

### Mark

Text processing together with **Copy** and **Insert**.

## Generation options

**Options** Open menu.

Send	Send MMS.
Preview	Play entire MMS on the display.
Picture...	See p. 48.
Sound...	See p. 49.
Text...	See p. 49.
Page...	<p><b>Add page:</b> Insert new page after current one.</p> <p><b>Delete page:</b> Delete current page.</p> <p><b>Page list:</b> Display available pages.</p> <p><b>Timing:</b> Enter the lifespan of a page in seconds.</p>
Msg. details	Enter sending parameters (p. 52).
Save as templ.	Save created MMS as a template. See also below.
Layout	<p>Select one of four possible layouts:</p> <p>Text above, beneath, beside (on left or right of) picture.</p>
Colour...	<p>Select the colours for:</p> <ul style="list-style-type: none"> <li>• <b>Picture backg.</b></li> <li>• <b>Text backg.</b></li> <li>• <b>Text colour</b></li> </ul>

(For standard functions see p. 16)

## Templates

 →  → MMS templates

MMS templates are MMS messages that are saved without an address. They can be sent as new MMS messages or used as part of a new MMS. A maximum of 10 templates can be saved.

Create templates by writing a new MMS or using an MMS which you have already received.


**Options** Open menu and select **Save as templ.**

## Sending

The page(s) of the new MMS is (are) already created and the MMS is displayed.




Open address entry.



**Subject:** Enter a brief description.

**Send to:** Enter one or more phone number(s) / e-mail address(es).

 Insert from Addressbook.

**Size:** Display the size of the current MMS in kilobytes (KB).

**Attachments:**

Insert attachments.



Start sending procedure.



The MMS is sent after confirmation.

## Expanded address fields



Scroll downwards.

**More:** Provide additional address fields.

**Cc:** Address(es) of copy recipient(s).

**Bcc:** Address(es) of copy recipient(s) who are not visible to the other recipients.

**Date:** Creation date.

**Use delivery time:** Use specified send time. If **Yes**:

**Delivery date:** Send date.

**Delivery time:** Send time.

## Symbols for status information



Priority



Send report



Contains DRM (p. 14).

## Sending options

**Options** Open menu.

Send	Send MMS.
Play	Play entire MMS on the display.
Edit	Display object selection so that object can be changed.
Add recipient	Add recipient from the current address directory.
Delete recip.	Delete individual recipient.
Add attachm.	Add attachment: <ul style="list-style-type: none"> <li>• Business card</li> <li>• Appointments</li> <li>• Picture</li> <li>• Video</li> <li>• Sound</li> <li>• File</li> </ul>
Page list	Display MMS pages for viewing and/or changing.
Save as templ.	Save created MMS as a template.

(For standard functions see p. 16)

## Receiving

Depending on the setting (p. 54), an MMS can be received in two ways:

### Complete transmission

The complete MMS is sent to your phone. This can take quite a while if the MMS is large.



Shown in the display.



Start reception.  
The MMS is sent.

### Preliminary notification

You are notified that an MMS is waiting to be received.



Shown in the display.



Open the notification.  
Display sender/date.



Display the properties of the MMS.

**Receive**

The complete MMS is sent.

**OK**

Display in Inbox.

## Reading

An MMS has been received in full.



Select the MMS.



Start automatic playing of the MMS.

Key functions for playback:



To the next page.



Press briefly once to return to the start of the current page; press briefly twice to return to the start of the previous page.



Set volume.



End.

The message details are displayed when the MMS is complete.

**Subject:** Description of the MMS.

**From:** Information about the sender.

**Size:** Size of the MMS in KB.

### Expanded address fields



Scroll downwards.

**More:** Additional input fields.

**Cc:** Copy recipient.

**Attachments:**

Save attachments.

**Date:** Date received.

Symbols for status information (see p. 51).

## Lists

All MMS messages are saved in four different lists (for overview of message symbols, see p. 7):

### Inbox



→ Inbox → MMS

The list of MMS messages and notifications received is displayed. To receive an MMS at a later time, open notification and press **Receive**.

### Draft



→ Draft → MMS

The list of stored drafts is displayed.

### Unsent



→ Unsent → MMS

The list of the MMS messages not yet fully transmitted is displayed.

### Sentbox



→ Sent → MMS

The list of sent MMS messages is displayed.

## List options

Different functions are offered depending on the list/situation.

**Options** Open menu.

Play	Play MMS on the display.
Edit	Display MMS for processing.
View	Display MMS for viewing only (write-protected).
Send all	Send MMS.
Reply to all	Reply to MMS immediately.
Forward	Enter recipient(s) for forwarding.
Msg. details	Display message parameters.
Receiv.all MMS	Send all new MMS messages immediately.
(For standard functions see p. 16)	

## Setting



### MMS profile:

Six MMS profiles can be set (5 in the telephone memory, one on the SIM card). The send properties can be specified in them. In most cases, they have already been set. If necessary, check with your service provider for details.

#### Activating a profile

Select profile.

**OK** Profile is activated.

#### Setting a profile

**Change** Display list of profiles.

Select profile.

**Edit** Press. Make settings.

## User settings

Set the MMS dispatch to suit your requirements:

<b>Delivery report:</b>	Request delivery confirmation for sent messages.
<b>Default priority:</b>	Send priority: Normal, High, Low
<b>Expiry time:</b>	Select the period of time in which the service centre is to try to deliver the message: Manual, 1 hour, 3 hours, 6 hours, 1 day, 1 week, Maximum* * Maximum period that the service provider permits.
<b>Page duration:</b>	Enter the lifespan of a page in seconds (standard requirement). Scroll forward in Manual or Automatic mode.

**Retrieval:** Receive complete MMS or only notification of arrival.

### Automatic

Receive complete MMS immediately.

### Auto.homenet


Receive complete MMS immediately in home network.

### Manual

Only receive the notification.

**Creation mode:** Free, Restricted, Warning

May be used to receive a warning message or to limit the size of the message.

**Size indication:** Set max. message size and message handling.  




# E-mail

Your phone has an e-mail program (client). You can use it to create and receive e-mails.

## Writing



→ Create new → E-mail

Enter the address details for the e-mail:

**Send to:** Enter one or more e-mail address(es).



Insert from Addressbook/Phonebook.

**Subject:** Enter e-mail heading (up to 255 characters).

**Content** Enter text.

### Expanded address fields

**All fields** Open additional input fields.

**Cc:** Address(es) of copy recipient(s).

**Bcc:** Address(es) of copy recipient(s) who are not visible to the other recipients.

### Attachments:

Add attachments such as images and sounds.

### To send:




Press.

## Options

Different functions are offered depending on the position of the cursor.

**Options** Open menu.

Send e-mail	Send e-mail.
Send later	Transfer e-mail into the Unsent list.
Save	Save e-mail in the Draft list.
Add recipient	Add recipient from the current address directory.
Delete line	Delete current line.
Insert...	Text module Bookmark Insert From  Addressbook/ Phonebook.
Add attachm.	My stuff Open to make a selection. Remember that pictures and sounds may be protected (DRM, p. 14).
Delete text	Delete the whole text.
Text input	<ul style="list-style-type: none"> <li>• T9 preferred</li> <li>• Input language</li> </ul>

## Receiving/reading



Before an e-mail can be read, it must be retrieved from the server. You have two options:

### Retr. e-mail

Only the message header in the **Inbox** (p. 41) is sent. You can then decide if you also want to receive the contents:

**Options** Open menu and select  
Retrieve body.

or if you want to delete the e-mail on the server:

**Options** Open menu and select  
Del. on server.

### Send/rec. mail

The set access is selected and all e-mails transferred to the **Inbox** (p. 41). At the same time, completed e-mails are transferred from the **Unsent** list.

## Attachments

Contains the e-mail attachments; these can be saved in **My stuff** (p. 113).

**Options** Open menu and select  
Save attach.

## Lists

All e-mails are saved in different lists depending on their status (for overview of message symbols, see p. 7):

### Inbox



The list of received e-mails is displayed.

### Draft



The list of e-mails not yet transmitted is displayed.

### Unsent



The list of e-mails not yet transmitted is displayed.

### Sentbox



The list of transmitted e-mails is displayed.

## List options

Different functions are offered depending on the list.

**Options** Open menu.

<b>Retr. e-mail</b>	Only transfer the message header into the <b>Inbox</b> (p. 41).
<b>Retrieve body</b>	Retrieve the contents from the server if only the message header was received.
<b>Del. on server</b>	Delete the contents on the server if only the message header was received.

(For standard functions see p. 16)

## Setting



## Accounts

Before using this service, you must set the server access and your e-mail parameters. Your service provider will supply you with this data.



Select account.

## Activating an account



Activate existing account.

## Setting an account



Start the processing and fill in the data fields as specified by the service provider.

## General sett.

Enter an e-mail address to which a **Bcc** (blind carbon copy) is **always** sent.

# Voice message/mailbox



Most service providers provide a mailbox in which a caller can leave a voice mail for you

- if your phone is switched off or not ready to receive,
- if you do not want to answer,
- if you are making a phone call (and if **Call waiting** (p. 80) is not activated).

If the voice mail service is not part of your service provider's standard package, you will need to register, and possibly adjust the settings manually. The following sequence may vary from service provider to service provider.

## Setup





The service provider supplies you with two phone numbers:

### Save mailbox number

You call this phone number to listen to the voice mails left for you.



  Select number from Phonebook/Addressbook or enter/change it.

**OK** Confirm.

### Save call divert number

Calls are diverted to this phone number.



Enter phone number.

Or

**Mailbox** Press to divert call to the mailbox number.

**OK**

Registration with the network is confirmed a few seconds later.

## Listening to message



A new voice message can be announced as follows, depending on the service provider:



Symbol plus beep.

Or



Notification via SMS.

Or

You receive a call with an automatic announcement.

Call your mailbox and play the message(s) back.



Press and **hold** (if necessary enter mailbox number once). Confirm with **OK** and **Mailbox** depending on your service provider.

## Inst. message



With **Inst. message** you can transfer text, audio clips, pictures and files straight to and from one or more terminals (mobile phone, PC). This function is not offered by all service providers. Please ask your service provider about this.

Your dialogue partners are entered in contact lists. When a connection has been established, these lists show who is available, whether he/she wants to be disturbed and what mood he/she is in at present.

**GPRS must be switched on.**

 →  → Inst. message

## Start menu

**Login** Select the access through which the dialogue is to take place

or

select **Account** (p. 65).

**Msg. history**

Read the messages from the last session.

**Setup**

Settings for your representation, the applications and servers.

**Quit**

End application.

## Fast access ...

### Select account (p. 65)



→ Inst. message → Login

The current contact list or the overview is displayed (if necessary, set account first, p. 65).

### Specify your own status (p. 66)

**Options** Open menu.

**My settings**

Select and make entries.



Return to contact list.

### Enter new contact

**Options** Open menu.

**Manage** Press, then:

**Add contact**

select and enter at least the user ID.



Return to contact list.

### Hold dialogue with new contact (p. 64)



Select the contact.



Start dialogue.



Open editor.



Write text.



Send text ...

... and so on.

## Login



Select the last account used (see also **Automatic login**: p. 66).

## Contact lists

When the connection has been established, the contact list or the overview of the contact lists is shown for selection.

In the contact list, you will find a list of the most recently used contacts. The first time you log in, an “empty” contact list will be generated by the server if necessary.

Displays in the list:

### -Conversation

Displays online contacts for whom there are messages.

### -Online

Online contacts with whom no conversations are being held at present.

### -Group

Groups for Inst. Messaging with several contacts.



### -Offline

Contacts who are not online at present.

## Managing contacts



Select a contact.

### Options

Open menu.

### Manage

Select.

## Contacts

Different functions are offered depending on the selection:

### Add contact

#### User ID:

Enter an unambiguous user (login) name.

#### Nickname:

Enter your own nickname for the contact.

#### Friend:

The contact receives the status **Friend**: and access to personal information (p. 66).

### Search contact

Search for contact.

### Delete contact

Delete contact from the list.

### Block contact

No more messages are received from the contact and the contact receives no status information from you. This function works for all your lists.

## Managing groups



Select one of the groups you set up yourself.

### Options

Open menu.

**Manage** Select.

### Manage group

Different functions are offered depending on the selection:

<b>Add member</b>	Add a new group member, see also <b>Add contact</b> .
<b>Search memb.</b>	Search for group member.
<b>Invite</b>	Invitation to the contacts in your own group to Inst. Message.
<b>Delete member</b>	Delete contact from the group member list.

<b>Add group</b>	Add new group.
<b>Search group</b>	Search for group on the server (also groups no longer managed in the list).
<b>Create group</b>	<p><b>Group ID:</b> Enter an unambiguous group name.</p> <p><b>Name:</b> Name of group.</p> <p><b>Topic:</b> Topic of group.</p> <p><b>Searchable:</b> Other people can look for the group.</p> <p><b>Welcome note:</b> Enter own greeting.</p>
<b>Delete group</b>	Delete group.

## Creating a new contact list

The current contact list is displayed.

**Options** Open menu.

### Contact lists

Available contact lists are displayed.

**Options** Open menu.

**Create** Select.

### Contact list ID:

Give the contact list an unambiguous name.


**Name:** Allocate self-explanatory name.



Confirm.

## Contact list options

**Options** Open menu.

**Details**  Additional information about the contact or the group.

**My settings** Information on your current personal status (p. 66).

**Manage** Functions for managing a contact or a group.

**Contact lists** Display contact lists for selection.

**Block listtp** Display all blocked contacts.  
Can be unblocked.

**Appl. settings** Set the application (p. 66).

**Suspend** End the application; the server remains connected.

**Logout** Log off from the server and return to start menu.

**Help** Display help text.



## Starting Inst. message

A contact list must be displayed.



Select a contact or a group.



Start communication with the contact.

The page with the **Inst. message** is displayed. When a group is engaged in a dialogue, the name of the sender is placed in front of each contribution.



Open editor.



Write text.



Send text. The text appears in the **Inst. message** soon afterwards.

Naturally, you can also receive messages from contacts you do not know. This will be pointed out to you in the display, and you can either switch to Inst. Message or ignore/block the contact.

## Options (individual contact)

**Options** Open menu.

**Send sound** Select and send a melody/sound from the list (DRM, p. 14).

**Send picture** Select and send a picture from the list (DRM, p. 14).

**Send any** Send any file.

**Details** Information about the contact, if they authorise this.

**Clear all** Delete all texts in the current Inst. Message.

**Block contact** No more messages are received from the contact and the contact receives no status information from you. This function works for all your lists.

## Options (group contact)



**Options** Open menu.

**Leave group** Exit group.

**Details** Information about the group:  
Group ID:, Name:, Topic:, Owner:

**Clear all** Delete all texts in the current Inst. Message.

## Receiving objects



If sounds or pictures are sent to you during a dialogue, you will be informed of such in the display.

**Receive** Accept object  
or

**Reject** Reject object.

## Msg. history

→ → Inst. message  
→ Msg. history

The messages from the last meeting are displayed. You can read and delete the contributions.

Requirement: The server must be disconnected, see **Suspend** (p. 63) and **Automatic login:** (p. 66).

## Setting

→ → Inst. message  
→ Setup  
→ Select function.

## Account

The list of available accounts is displayed.

Select an account to establish a connection.

Or

<New entry>/Account sett.

Set up an account or change the settings as specified by the service provider. Depending on the service provider, the settings may not be changeable.

<b>Name:</b>	Name of account.
<b>URL:</b>	Enter URL, e.g. www.abc.com
<b>User ID:</b>	Enter an unambiguous user (login) name.
<b>Password:</b>	Enter password (shown as a series of asterisks).

## My settings

Information on your current personal status:

<b>Alias:</b>	Your own alias under which you can be found on the server.
<b>Screen name:</b>	Name to be displayed in the group.
<b>Mood:</b>	Information about your own mood, e.g. Happy, Sad, Sleepy etc.
<b>Status text:</b>	General text information, e.g. "Am at home".
<b>Availability:</b>	Availability: Available, Not available, Discreet
<b>Mobile:</b>	Enter the phone number with international dialling code.

### Options

For **each** setting, specify who is allowed to view your personal information:

#### Public

All contacts.

#### Private

Contacts designated as **Friend**: (p. 61).

#### Hidden

Nobody.

## Appl. settings

Settings for the application used:

<b>Automatic login:</b>	Auto-reconnect to the last account used.
<b>Timeout:</b>	Time without action after which the application is terminated. However, the server remains connected.
<b>Message info:/ Online info:</b>	Signal the receipt of messages: Yes/No Signal given as: <ul style="list-style-type: none"> <li>• Sound</li> <li>• Silent alert</li> <li>• Pop-up Pop-up windows authorised: Yes/No</li> </ul>

# CB services



Some service providers offer information services (info channels, **Cell Broadcast**). If reception is activated, you will receive messages on the activated topics in your **Topic list**.

CB messages are displayed in standby mode; longer messages are scrolled automatically.

## Receive CB

You can activate and deactivate the CB service. If the CB service is activated, standby time for the phone will be reduced.

## Topic list

You can add any topics to this personal list from the topic index. You can preset 10 entries with their channel numbers (ID) and, if applicable, with their names.

**New topic** Select.

- If no topic index is available, enter a topic with its channel number and confirm with **OK**.
- If the topic index has already been transmitted, select a topic and activate it with **Options**.

**Topic** Select

**Options** Open list menu.

If a topic is selected in the list you can view it, activate/ deactivate it, edit it or delete it.

## CB languages

Receive Cell Broadcast messages in only one specific language or in all languages.

### Displays

- |  |                                     |
|--|-------------------------------------|
| <input checked="" type="checkbox"/> , <input type="checkbox"/> | Topic activated/deactivated.        |
|  | New messages received on the topic. |
|  | Messages already read.              |

## Text zoom

You can set three fixed sizes for the presentation of the display texts across the entire message range:

**Standard** Medium font size

**Zoom +** Large font

**Zoom -** Small font

# Surf & fun

Obtain the latest information from the Internet that is specifically adapted to the display options of your phone. In addition, you can download games and applications to your phone. Internet access may require registration with the service provider.

## Access to the service provider

Direct call-up of the browser with the URL from your service provider.

## Internet



The browser is activated with the pre-set option as soon as you call up the function (Browser settings, p. 69; may be specified/pre-assigned by service provider).

## Browser menu

**Options** Open menu.

**Homepage** Call up the pre-set homepage for the current profile.

**Bookmarks** List bookmarks  
Display list of bookmarks stored in the phone.  
**Bookmark site**  
The current page is saved as a bookmark.

**Go to...** Enter URL to dial an Internet address directly, e.g. **wap.siemens.com**

**Reload** Reload current page.

**Show URL** Display the URL of the page currently loaded for sending via SMS/MMS/e-mail.

**History** Display most recently visited Internet sites.

**Disconnect** Disconnect the Internet.

**File** Save object on the current page or save the complete page; display saved pages.

**Setup** Set or reset browser (p. 69).

**Exit browser** Close the browser.

## Ending a connection



Press and **hold** to clear down the connection and close the browser.

## Navigation in the browser



- Select a link.
- Settings, status on/off.



- Press **briefly**: one page back.



- One input field/link forward/back.
- Scroll one line.

## Display symbols in the browser (selection)



Connect



No network



Network



GPRS online

## Entering special characters



Table of special characters (p. 20).



List of special characters, depending on the situation.

## Browser settings



Internet

### Options

Open menu.

### Setup

Select.

### Browser

Set start option as well as handling of pictures# and sounds plus send options.

### Profiles

The list of profiles is displayed for activation/setting. For more information, contact your service provider.

### Protocol parameters

Set protocol parameters, push messages and abort time as well as handling of cookies.

### Security

Set encryption.

### Context

Reset session; delete cache, history and cookies.

Your Internet browser is licensed by:



OPENWAVE™



## Profiles

Preparation of the phone for Internet access depends on the service provider concerned:

### Profil pre-set

In most cases, access profiles have already been created for one or more service provider(s).



Select profile.



Activate profile.

### Setting a profile manually

If necessary, please contact your service provider.

**Options** Open menu.

**Edit** Start processing. For the Internet-specific settings below, please contact your service provider.

**Delete** Delete selected profile.

## Bookmarks



→ Bookmarks

### Displaying URL/call up page

#### List bookmarks

Display list of bookmarks stored in the phone.



Select bookmark.



Call up URL.

## Saving

### Bookmark site

The current page is saved in the phone as a bookmark.

### Bookmark options

**Options** Open menu.

Here you will find functions for changing and managing bookmarks and their folders. This includes editing individual entries with the corresponding URLs as well as deleting and moving them to other folders.

## Games and Applications

Games and applications are offered on the Internet. Once downloaded, you can access these via the phone. Most applications include instructions. Some applications and games are already pre-installed on your phone. You will find these described under [www.siemens.com/sp65](http://www.siemens.com/sp65)

### Requirements

Browser profile (p. 69) and access (p. 88) must be configured already.

### Downloading

Select the correct access depending on whether you are loading games or applications:



or



Load or start games, or else start applications or reload them with Download Assistant .

### Description file only



The description file is loaded for information purposes only. The application/game itself must be loaded separately.

### or complete download



The application/game is completely loaded.

### Applying

Remember that applications/games may be protected (DRM, p. 14).



The executable application is saved on the phone and can be started immediately.

### Downl. assist.



You will not be left on your own during the download.



## Games&More options

Processing and managing your applications and folders:

<b>Move</b>	Move applications between folders.
<b>New folder</b>	Create and name new folder.
<b>Update</b>	Reinstall an application (update).
<b>Security</b>	Select a security level.
<b>Reinstall</b>	Repeat after transmission error.
<b>Attributes</b>	Show details of the application/folder (name, version, size, path, producer, date).
<b>HTTP profile</b>	Display profile list for activation/setting
(For standard functions see p. 16)	

### Additional information

You can use the browser to download applications (e.g. ringtones, games, pictures, animations) from the Internet.

Siemens excludes all warranty and liability claims in respect of or in connection with any applications subsequently installed by the customer and any software not included in the original delivery package. This also applies to functions enabled subsequently at the customer's instigation. The buyer bears the sole risk for loss, damage or faults to the phone or application as well as all damage and implications arising from the application. For technical reasons, such applications or the retrospective release for certain functions may be lost if the phone is exchanged/re-delivered or repaired. In such cases, the buyer is required to download or release the application again. Please ensure that your phone has Digital Rights Management (DRM) so that downloaded applications are protected from unauthorised reproduction. These applications are then exclusively intended for your phone and cannot be transferred from this even to create a backup. Siemens offers no warranty or guarantee nor does Siemens accept any liability for the customer's ability to download or enable applications again or to do so free of charge. We recommend that you back up the applications from time to time on a Windows® PC using the "Mobile Phone Manager" ([www.siemens.com/sp65](http://www.siemens.com/sp65)), p. 115.

# Setup

## Profiles



Several settings can be stored in a phone profile in order, for example, to adapt the phone to the surrounding level of noise.

- Five standard profiles are provided with default settings. They can be changed however:

Normal environment

Quiet environment

Noisy environment

Car Kit

Headset

- You can set two personal profiles (<Name>).
- The special profile **Aircraft mode** is fixed and cannot be changed.

## Switching on



Select default profile or personal profile.



Switch on profile.

## Profile settings

Edit a default profile or create a new personal profile:



Select profile.



Open menu.

**Change sett.**

Select.

The list of available functions is displayed.

When you have finished setting a function, return to the profile menu where you can change a further setting.

### Additional information

Call up the list in standby mode:



The profile list is displayed.

The active profile is identified with

## Profile options

**Options** Open menu.

**Activate** Activate selected profile.

**Change sett.** Change profile settings.

**Copy from** Copy settings from another profile.

**Rename** Change personal profile (except default profiles).

## Car Kit

If an original Siemens car kit is used, the profile is switched on automatically when the phone is inserted into the cradle (also see accessories).

## Headset

The profile is only switched on automatically if an original Siemens headset is used (also see accessories).

## Aircraft mode

All alarms (appointments, alarm clock) are deactivated. This profile **cannot be modified**.

### Switching on



Scroll to **Aircraft mode**.



Confirm selection.



Confirm safety inquiry again in order to activate the profile. The phone switches itself off automatically.

### Normal mode

When you switch on your phone again, the previously set profile will be reactivated automatically.

## Themes



Load a completely new visual presentation onto your phone. At the press of a key various functions are re-organised on a theme basis, e.g.

Start up/shut down animation, wallpaper, screensaver, start up/shutdown melody, additional animations.

Theme files are compressed to save memory space. After being downloaded or called up from **My stuff**, these are automatically unzipped when activated.

## Activating a new theme



Select theme.



Display theme preview.



Activate new theme.

## Display setup




→ → Display setup  
→ Select function.

### Language

Set the language for the display text. When “automatic” is set, the language of your home service provider is used.

If a language that you do not understand happens to be set, the phone can be reset to the language of your home service provider with the following input (in standby mode):

\*#0000# 

### Text input

#### T9 preferred

Activate/deactivate intelligent text entry.

#### Input language

Select language for text entry. Languages with T9 support are marked with the T9 symbol.

## Wallpaper

Set wallpaper graphic for the display.

### Logo

Choose graphic to be displayed instead of the provider logo.

### Colour skin

Select colour skin, incl. background image for the entire user interface.

### Screensaver

After a specifiable time, the screen-saver shows a picture in the display. An incoming call and/or pressing any key will end the function except if the safety function is activated.

#### Changing settings:

**Change** Settings are displayed.

#### Preview

Display the screensaver.

#### Style

Select **Analogue clock**, **Digital clock**, **Bitmap**, **Energy saving**

#### Bitmap

Select image in **My stuff**.

**Timeout:**

Set period after which the screen-saver starts.

**Code protection:**

The phone code is requested to close the screensaver.

**Auto key lock:**

Automatic keypad locking if no key has been pressed for one minute in standby mode.

**Unlocking:**

Press and **hold**.

**Note**

The animated **Bitmap** screensaver and the **Digital clock** considerably reduce the phone's standby time.

**Start up anim.**

Select animation to be shown when phone is switched on.

**Shutdn anim.**

Select animation to be shown when phone is switched off.

**Own greeting**

Enter greeting to be displayed instead of animation when phone is switched on.

**Big letters**

You can choose between two font sizes for the display.

**Illumination**

Set display illumination to brighter/darker. The darker the setting the longer the standby time.



Press the joystick repeatedly at the top/bottom to adjust up or down.

## Ringtones



Set the signal tones on the phone to suit your requirements.


### Ringer setting

**On/off**      Activate/deactivate all tones.

**Beep**        Reduce ringtone to a short signal (beep).


### Silent alert

To avoid the disturbance caused by a ringing phone, you can activate the silent alert function as an alternative. The silent alert can also be activated in addition to the ringtone (e.g. in noisy environments). This function is deactivated when the battery is being charged and accessories are connected (except the headset).



## Volume

Set different volumes for types of call/functions.



### Additional information

Please make sure you have accepted the call before holding the phone to your ear. This will avoid damage to your hearing from loud ringtones.

## Assigning a ringtone

A ringtone which has already been selected will be played or the list of possible ringtones will be displayed for selection.

### Calls

Assign a single ringtone to all phone numbers in the Addressbook.

### Group calls

Assign a different ringtone to each group.

### Other calls

Assign one ringtone to the remaining calls.

## More melodies

Assign further ringtones for:

Messages

Alarm clock

Organiser

Startup melody

Shutdown mel.

or record new with:

Sound recorder (p. 111)

You will find a list of all supported formats for ringtones in **My stuff** (p. 112).



## Call setup



### Hide ID

When you make a call, your phone number can be displayed on the recipient's display (depending on the service providers).

To suppress this display, you can enable the "Hide ID" mode for all subsequent calls or just for the next call. You may need to register separately with your service provider for these functions.

### Call waiting

If you are registered for this service, you can check whether it is set and you can activate/deactivate it.

### Divert

You can specify the conditions under which calls should be diverted to your mailbox or other numbers.

#### Status check

You can check the current divert status for all conditions. After a short pause, the current situation is transmitted by the network and displayed.

- Condition set.
- Not set.
- ? Display if status is unknown (e.g. with a new SIM card).

#### Clear all

All set diversions are cleared.

### Setting up call divert (example)

The most common condition for call divert is, for example:

#### Unanswered



Select **Unanswered**.  
(Includes the conditions **Not reachable**, **No reply**, **Busy**, see below)



Confirm.

Set

Select.



Confirm.



Select or enter the phone number to which the calls are to be diverted.

**Mailbox** Use existing mailbox phone numbers, or enter them if necessary.

**OK**

Confirm. After a short pause, the setting is confirmed by the network.

## All calls



All calls are diverted.



Symbol in the top line of the display in standby mode.

## Not reachable

Divert occurs if phone is switched off or is out of range.

## No reply

A call is only diverted after a delay that is determined by the network. The period can be set to a maximum of 30 seconds in 5-second intervals.

## Busy

Divert occurs if a call is in progress. If **Call waiting** is activated (p. 25), you will hear the call waiting tone during a call (p. 27).

## Receiving fax



Fax calls are diverted to a number with a fax connection.

## Receiving data



Data calls are diverted to a phone number with a PC connection.

### Additional information

Note that the divert is stored in the network and not in the phone (e.g. when the SIM card is changed).

### Reactivate divert


The last divert has been stored. Proceed as with "Set divert". The stored phone number is displayed. Confirm number.

## Call screening



Only calls from phone numbers that are in the Phonebook/Addressbook or assigned to a group are signalled. Other calls are only displayed.

## Any key answ.

Incoming calls can be accepted by pressing any key (except for )

## Minute beep

During the call, you will hear a beep after each minute as a reminder of the time elapsed. The person you are talking to does not hear this beep.

## Phone setup



→ → Phone setup  
→ Select function.

### Key tones

Set the type of acoustic key acknowledgement.

### Info tones

Set service and alarm tones:

**On/off** Activate/deactivate tones.

**Extended** If switched on, a wider range of service tones is available, e.g. end of menu reached, network connection interrupted.

### Auto off

The phone switches off each day at the set time.

#### Activating

**Time** Press.



Enter time  
(24-hour clock).

**OK** Confirm.

#### Deactivating

**Manual** Press.

**OK** Confirm.

## Phone identity

The phone identity number (IMEI) is displayed. This information may be useful for customer service.

### Device check

After the last information page, a self-test as well as individual tests are offered. If you select **Selftest**, all individual test are carried out.

#### Software version

Display the software version for your phone in standby mode:

\* # 0 6 #, then press **More**.

## Memory assis.

The memory assistant will help you if there is insufficient phone memory. If required it can also be started automatically from applications.

After their capacities have been checked, all files and folders are displayed along with their size and may be viewed/opened and, if necessary, deleted.

## File system

### Format

(Phone-code protected)

The telephone memory is formatted and **all** saved data such as ringtones, pictures, games, etc. is deleted.

Formatting may take longer than one minute.

### Clean up

Create more memory by deleting temporary files no longer required.

### Format card

All data on the RS MultiMediaCard™ is deleted.


### Eject card

Allows the card to be removed from the phone.

## Master reset

The phone is reset to default values (factory setting). This does not affect the SIM card or the network settings.

Alternatively, in standby mode enter:

**\*#9999#** 

## Clock



### Time/date

The clock must be set correctly once, at start-up.

**Change** Press.



First enter the date (day/month/year), then the time (hours/minutes/seconds).

#### Additional information

If the battery is removed for longer than 30 seconds, the clock must be reset.

### Time zones

The time zone can be selected in the world map or a city list:

#### World map



Select the desired time zone.

#### City list



Select a city in the selected time zone.

**Options** Open menu.

**Set** Set time zone.

**Auto time zone** Have the time zone automatically set by the network.

**Search city** Search for a city.

**Help** Operating instructions.

### Date format

Select the display format for the date.

### Time format

Select 24h or 12h.

### Buddhist year

Switch to the Buddhist year (not on all phone models).

### Show clock

Activate/deactivate time display in standby mode.

### Auto time

The timezone is identified automatically.




## Connectivity



### GPRS



(General Packet Radio Service)



GPRS is a method for transmitting data faster in the mobile network. Use GPRS and if the network has sufficient capacity, you can be connected to the Internet permanently. The network provider charges only for the volume of data transmitted. Some service providers do not yet support this service.

Shown in the display:

	Activated and available.
	Registered.
	Temporarily interrupted.

### GPRS info

Display the transmitted volume.


## IrDA



Your phone has an infrared interface. With this interface, you can exchange data such as pictures, ringtones, Addressbook entries, business cards or organiser data with other devices which also have an infrared interface.

The infrared interface is on the left side of the phone. The distance between the two devices must not exceed 30 cm/12 inch. The infrared windows in both appliances must be aligned as accurately as possible with each other.

Shown in the display:



If IrDA is activated, standby time for the phone will be reduced.

## Bluetooth® (BT)

Bluetooth is a short-range radio connection by means of which a headset or car kit, for example, can be connected without the need for wires. Using the **Send/print** function in the options menu for the application concerned you can also use this route to send data.

With SAP (SIM Access Profile) a car phone GSM module can, for example, use the access data from the SIM card on your phone. There is no need to swap the SIM card. It is possible that SAP might not be supported by your service provider.

Each Bluetooth device has its own specific address and can be given a self-explanatory name as an option. Password protection ensures the security of a Bluetooth connection, as does including the BT partner in a list as a “confidential” device.

To establish a Bluetooth connection between your phone and other Bluetooth devices you must activate Bluetooth.

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc and any use of such marks is under licence. Other trademarks and trade names are those of their respective owners.



Activate/deactivate Bluetooth.

**My BT name:** You can give the phone a name when you activate Bluetooth for the first time.

If Bluetooth is activated, IrDA (infrared) is not active and vice versa.

If Bluetooth is activated, standby time for the phone will be reduced.


### Bluetooth setup



Call up the setting functions (Bluetooth must be activated).

- **Search/Search all**

Specify which BT devices are to be searched for:

<b>All</b>	All BT devices
<b>Audio</b>	E.g. headset, car kit
<b>Phone</b>	Other BT phones
<b>PC</b>	Personal computer with BT connection
	Start search

The number and name of the most recently found BT device are displayed.



The search is ended and the first 10 devices found are shown in a list.

**Retry** Start new search.



Scroll to entry required.



Dial the device or start the procedure for acceptance as a “confidential” device (see below).

### Options

Open menu.

<b>Details</b>	Display the name and address of the BT device.
<b>Trusted dev.</b>	Add the device as confidential to the list of known devices. To do this, enter the password for the other device. The device must first be set to a “confidential mode”. If the list is full it is not possible to add another device.
<b>To known list</b>	Add to the list of known devices (see below).
<b>To black list</b>	Add to the black list (see below).
<b>Retry</b>	Start new search.

### • Known devices

To make selection easier, frequent BT partners can be recorded in the known device list. If entries are “confidential”, no password query is made.

### • Last connect.

List of most recently and/or still connected devices.

### • Black list

Attempts to make connections to devices in this list are rejected.

### List options

Each list offers different functions.

**Options** Open menu.

<b>Mark as audio</b>	If not possible automatically, specify device as an “audio” device.
<b>Increase prio.</b>	Move entry up the list so that, for example, a specific audio device is used first.
<b>Decrease prio.</b>	Move entry down the list.
<b>To known list</b>	Move entry to the list of known devices.
<b>To black list</b>	Move entry to the black list.

(For standard functions see p. 16)



- **My BT name**

The phone is given a name (max. 16 characters) – this is the name the partner sees. If no name is given, the phone uses the non-changeable device address.

- **Visib.to others**

Set how your phone should respond to other BT devices. This means (if “visible”) for example that the device address or the BT name of your phone is shown to other BT devices if they request this in order to receive or send data.

- **Not visible**

Your phone is not “visible” to other BT devices. Known devices such as Bluetooth™-Headset/Car Kit continue operating.

- **Auto mode**

Your phone is not “visible” to other BT devices for several minutes. You will then be asked if “visibility” should continue.

#### Shown in the display



Bluetooth activated.



Bluetooth visible to others.



Bluetooth during data transfer.



Call to Bluetooth device accepted.

## Data services

Basic setting and activation of the connection profiles for data transmission such as **MMS**, **WAP**.

The phone default setting varies from service provider to service provider:

- The settings have already been implemented by the provider. You can start immediately.
- Access profiles have already been created by your provider. Then select and activate profile.
- The access profiles must be configured manually.

If necessary, check with your service provider for details. You will also find the current settings for the service provider on the Internet at [www.siemens.com/mobilephonescustomercare](http://www.siemens.com/mobilephonescustomercare) in the FAQ section.

### Selecting a profile



Select the profile.



Confirm selection.

## Setting a profile



Select the profile.

### Options

Open menu.

### Edit

Open the selection.



Select **CSD settings**, and/or **GPRS settings**.

### Edit

Make the settings as specified by your service provider.

## HTTP profile

The phone default setting varies from service provider to service provider:

- The settings have already been implemented by the provider. You can start immediately.
- Access profiles have already been created by your provider. Then select and activate profile.
- The access profiles must be configured manually.

If necessary, check with your service provider for details. You will also find the current settings for the service provider on the Internet at [www.siemens.com/mobilephonescustomercare](http://www.siemens.com/mobilephonescustomercare) in the FAQ section.



Make the settings.

## Authentication

Activate or deactivate encrypted dial-up (CSD connections only) for Internet access.

## Fax/data

### Fax/data mode using a PC

With the phone and a connected PC, you can transmit and receive faxes and data. Appropriate software for fax and data communication must be available on your PC and there must be a connection to the phone.

Fax and data services must be enabled by the service provider. There are variations in fax and data reception, depending on the network. Please ask your service provider about this.

### Send voice/fax


Set this function on the phone **before** transmission so that you can switch from voice mode to fax mode.

### Rec. voice/fax

(**Only** if no special fax or data number is available)

Start the required communication program on your PC and activate the function on the phone **during** the call (the PC will take over the connection).

**End transmission**

End transmission with PC software and/or press .


**Rec. fax/data**

Your service provider has given you a number for telephoning and a fax/data number.

The call is signalled by a special ringtone and the type of call (fax or data) is displayed. Now start the communication program on your PC to receive the fax/data.

## Security



→  → Security  
→ Select function.

### Auto key lock

The keypad is locked automatically if no key has been pressed for one minute in standby mode. This prevents the phone from being used accidentally. However, you can still be called and you can still make an emergency call.

#### Additional information

The keypad can also be directly locked and unlocked in standby mode.

In each case:



Press and hold.

### Direct call

(Phone-code protected)

Only **one** phone number can be dialled (see also page 28).

### Only



(PIN2 or phone-code protected)

Dialling options are restricted to SIM-protected phone numbers in the Phonebook. If only area codes are entered, relevant phone numbers can be added to these manually before dialling.

If the SIM card does not support PIN2 input, the **whole** Phonebook can be protected with the phone code.

### PIN codes

For description, see page 18:

**PIN control, Change PIN, Change PIN2, Chg.phonecode**

### This SIM only



(Phone-code protected)

The phone can be connected to a SIM card once the phone code is entered. Unless the phone code is known the phone will not operate with a **different** SIM card.

If the phone is to be used with a different SIM card, enter the phone code when requested.

## Barrings



Barring restricts the use of your SIM card (not supported by all service providers). You need a 4-digit network password for network barring. Your service provider will give you this password. You may need to be registered separately for each barring.

### Outgo. access

All outgoing calls except emergency numbers are barred.

### Outgoing intl.

(International outgoing)

Only national calls can be made.

### Out.int.x.home

(International outgoing without home country)

International calls are not permitted. However you can make calls to your home country when abroad.

### All incoming

The phone is barred for all incoming calls (forwarding all calls to mailbox provides a similar effect).

## When roaming

You do not receive calls when you are outside your home network. This means that no charges are incurred for incoming calls.

### Status check

The following information can be displayed after a status check:



Barring set.



Barring not set.



Status unknown  
(e. g. new SIM card).

### Clear all

All barrings are deleted. A password which the service provider will give you is necessary for this function.

## Network



### Line



This function is only displayed if it is supported by the service provider.

**Two separate** phone numbers must be registered on the phone.

#### Select line

Select the currently used phone number.



Display current phone number.

#### Protected

(Phone-code protected)

You may limit usage to one phone number.

#### Additional information

Special settings may be made for each phone number (e.g., melody, call divert etc.) To do this, first switch to the required phone number.

Switch from phone number/connection in standby mode:



Press.



Press.

## Network info

The list of GSM networks currently available is displayed.



Indicates non-authorized service providers (depending on SIM card).

## Choose network

Network search is restarted. This is useful if you are **not** on your home network or want to register on a **different** network. The network list is rebuilt when **Auto network** is set.

## Auto network

Activate/deactivate, see also **Choose network** above. If “Automatic network” is activated, the next network on the list is dialled in ranking order of your “preferred networks”. Otherwise a different network can be selected manually from the list of the available GSM networks.

## Pref. network

Enter your preferred service providers here for when you leave your home network (e.g. if there are differences in price).

Your service provider is displayed:

**List** Display list of preferred networks.

Create/change entry:

<Empty> or select an existing entry, then select a new service provider in the list and confirm.

Record new service provider (last entry in the list):

#### Furth.network

Select, enter the provider data and save it.

#### Additional information

If you are outside your home network, your phone automatically dials another GSM network.

If the signal strength of the preferred network is inadequate when you switch on the phone, the phone may register in a different network. This can change when the telephone is next switched on or if another network is selected manually.

#### Band selection



Select either GSM 900, GSM 1800 or GSM 1900.

#### Fast search

When this function is active, network reconnection is speeded up (standby time is reduced).

#### User group



Depending on the service provider, you can create groups with this service. These can have access to internal (company) information, for example, or special rates apply. Please check with your service provider for details.

#### Active

Activate/deactivate function. "User group" must be deactivated for normal phone use.

#### Select group

You can select or add groups other than preferred groups (see below). Code numbers for the groups are obtained from your service provider.

#### Outgo. access


In addition to network control for a user group, it is possible to set whether outgoing calls outside the group are permitted. If the function is deactivated, only calls within the group are permitted.

#### Pref. group

If activated, calls may only be made within this standard user group (depending on the network configuration).

## Accessories



-  → Accessories  
→ Select function.

### Car Kit

Only in combination with an original Siemens handsfree car kit (see p. 125). The car kit profile is activated automatically when the phone is inserted into the cradle.

#### Auto answer

(factory default: off)

Calls are accepted automatically after a few seconds. Eavesdropping is possible!



Shown on the display.

#### Automatic switch off

(factory default: 2 hours)

The phone is powered by the car's power supply. You can adjust the time between switching off the ignition and the time at which the phone switches off automatically.

#### Car loudspk.

Improves playback in certain circumstances.

### Automatic settings

- Permanent illumination: switched on.
- Key lock: switched off.
- Charging the phone battery.
- Auto. activation of the car kit profile when phone is inserted in the cradle.

### Headset

Only in conjunction with an original Siemens headset (see accessories). If an original Siemens headset is used the profile is automatically activated when the headset is plugged in.

#### Auto answer

(factory default: off)

Calls are accepted automatically after a few seconds (except where the ringer is switched off or set to beep). You should therefore be wearing the headset.

#### Automatic setting

Accept call with Call key or PTT key (Push To Talk), even when the auto key lock is activated.

#### Auto answer

If you do not notice that your phone has accepted a call, there is the danger that the caller may eavesdrop.



# My menu



Press.

**My menu** Press.

Create your own menu with frequently used functions, phone numbers or Internet pages.

The list of 10 entries is preset. You can, however, change it as you wish.

## Using



Select the required entry.



Confirm.

**Or**



If the entry selected is a phone number, you can also dial it with the Call key.

## Changing the menu

You can replace each entry (1–10) with another entry from the selection list.



Select the required entry.

**Change**

The function list is opened for selection.



Select the **new** entry from the list.



Confirm. The entry is saved.

If **Phonebook** is selected, the phone number must also be selected; if **Internet** is selected, the bookmark must also be selected.

## Reset all


(Phone code required)

**Reset all**

Select. After a security prompt, the pre-assignment is reset.



# Fast access

You can assign one important phone number or function to each of the two soft keys and number keys 2 to 9 (speed-dial numbers). The phone number can then be dialled or the function can be started at the touch of a button.



## Additional information


The service provider may have already assigned functions to a soft key (e.g. access to “SIM services” or direct call-up of the Internet portal). It may not be possible to modify this key assignment.

The left soft key may sometimes be replaced automatically by  /  to access a new message for example.

## Soft keys

### Changing

For example, the **Internet** function is assigned to the soft key. To change this (in standby mode):

- Internet** Press **briefly**.
- Change** Scroll to new assignment in the list.
-  Confirm.

- Special case **Phone number**. Choose a name from the Phonebook/ Addressbook for assignment to the key.
- Special case **Bookmark**. Scroll to a URL in the bookmark list for assignment to the key.

### Apply

In standby mode:

#### Application

The “Internet” is just used as an example here.

- Internet** Press and **hold**; the application is started.

#### Phone number

The assignment “Carol” is used here only as an example.


- Carol** Press and **hold**. The phone number is dialled.

## Speed dialling keys

Number keys 2 to 9 can be used as speed dialling numbers for fast access. Number key 1 is reserved for the mailbox phone number (p. 59) and number key 0 is reserved for switching between two connections during use (p. 93).

## Changing

In standby mode:

 Press number key **briefly** (e.g. the 3).

If this number is still free:

**Set** Press.

Select a new function from the list and confirm with **OK**.

**Or**

If an assignment has already been made to this key (assignment displayed above the right soft key) e.g. **Games**

**Games** Press **briefly**.

**Change** Scroll to application in the list.



Confirm.

- Special case **Phone number**. Choose a name from the Phonebook/ Addressbook for assignment to the key.
- Special case **Bookmark**. Scroll to a URL in the bookmark list for assignment to the key.

## Applying

Select a stored phone number or start a stored application (e.g. **Calendar**).

In standby mode:

 Press **briefly**.

The assignment of the number key 3 is displayed above the right soft key e.g.:

**Calendar** Press and **hold**.


**Or simply**

 Press and **hold**.

# Organiser

 →  → Select function.

Or

 Press plus/minus key briefly.

## Calendar

 →  → Calendar

You can enter appointments in the calendar. Time and date must be set for the calendar to work correctly.


The calendar offers you three views:

### Monthly view

Special colour coding:

Day with entries for appointments, day-long appointments, weekends.

Navigation:

 One day forward/back.

 One week forward/back.


 Daily view open.


### Weekly view

Special displays:

Appointments are shown as a horizontal colour bar on the vertical hour division.

Navigation:

 One day forward/back.


 Forward/backward by the hour through the day.


### Daily view

Special displays:

Description of appointment.

Navigation:

 One day forward/back.

 To the start/end of the day or next/last entry.

## Calendar setup

 →  → Calendar setup

**Start of day:**

Time when the working day begins.

**Start of week:**

Weekday on which the monthly and weekly view on the left starts.

**Set weekend**

Set the days for the weekend.

**Show birthdays:**

Shown in the display

### Synchronising with a PC

With the mobile phone manager, (p. 115) you can synchronise appointments, tasks and memos with Outlook® or Lotus Notes™.

# Appointments



→ Appointments

Appointments are displayed in chronological order in a list.

## Entering new appointment

<New entry>

Select.

### Category:



**Memo**

Text input for description.



**Voice memo**

Enter voice memo.  
Shown with alarm.



**Call**

Enter phone number to be displayed with the alarm.



**Meeting**

Text input for description.



**Holiday**

Enter start and end date.



**Birthday**

Enter name and date.

Different input/selection fields are displayed depending on the type. The number of fields can be restricted, see **Standard**, p. 101.

### Description:

Description of nature of appointment.

### Phone number:

Enter a phone number or select one from the Addressbook.

### Voice memo:

Enter a voice recording, see **Dictat.machine**, p. 103.

### Location:

Location of appointment.

### Whole day:

All-day appointment: Yes/No

### Start date:

Date when appointment starts.

### Start time:

Time when appointment starts.

### End date:

Date when appointment ends.

### End time:

Time when appointment ends.

**Alarm time:**

On/off or Silent alert.



Enter the period of time **before** the appointment and select the time unit:

Minutes, Hours, Days

**Reoccurrence:**

Select a timeframe for repeating the appointment:

No, Daily, Weekly, Monthly, Yearly

Enter a parameter for repeating:

Forever, Until, Occurrences (number)

If **Weekly** is selected, certain weekdays can be highlighted.

**All fields/Reduced fields**

In the list, select those fields which are to be offered for future entries.

**Additional information**

Display above set alarms:



Alarm clock



Appointment

An alarm sounds even when the phone is switched off (except in aircraft mode, p. 74). The phone does not go to standby mode. Press any button to switch the alarm off.

**Information on the alarm**

When the set date and time are reached there is an audio and a visual alarm. If an alarm is missed it appears in the list of missed appointments (p. 102).

Alarm type **Memo**:

**Meeting**: The text is shown in the display.

Alarm type **Call**: The phone number is displayed and can be dialed immediately.

Alarm type **Birthday**: You can send special birthday greetings by SMS, MMS, e-mail or a call via **Options**.

Use **Snooze** to set the alarm to repeat.

**Tasks**

→ Tasks

A task is displayed like an appointment in the agenda of the selected day. However, unlike an appointment it does not require a time. When no time is entered the task appears at the top of the list every day until it is marked as completed.

The entries are made in the same way as **Appointments** (see "Appointments"). Then:

**Status:**

Select **Done** or **Outstanding**.

**Priority:**

Select 5 levels from **Lowest** to **Highest**.

**Date in use:**

If activated with **Yes**, the following time input option is offered.

**Due date:/Due time:**

Enter the date and time by which the task is to be completed.

**Alarm:** As for **Appointments**.

## Notes



Write and manage brief text notes.

### Entering a new note

<New entry>

Select.



Enter text. The first line is displayed as a “title” in the notes list. Total length: max. 160 characters.

**Options**

Open menu.

**Save**

Save note.

When **Confidential** is selected, a note is protected with the phone code.

## Missed appts.



Events with an alarm (**Appointments**, **Tasks**) to which you have not reacted are listed for reading.

## Organiser options

Depending on the application used (**Calendar**, **Appointments**, **Tasks**, **Notes**) and the current situation, different functions are offered.

**Options** Open menu.

<b>Delete</b>	Delete entry.
<b>Delete until</b>	Delete all entries prior to a certain date.
<b>Delete all</b>	Delete all entries after confirmation.
<b>Delete done</b>	Delete all completed tasks.
<b>Activate/Deactivate</b>	Switch alarm on/off.
<b>Filter</b>	Display all entries with the selected feature.
<b>Confidential</b>	Protect note with phone code. We recommend that you do not store any passwords (PIN, TAN etc.) as notes.

(For standard functions see p. 16)

## Dictat.machine



Use the dictating machine to record short voice memos.

- Use your phone as a dictating machine when on the move.
- Record a memo as a reminder or as a note for others.
- Add a voice memo to an appointment in the calendar.

## New recording

<New entry>

Select.

The remaining time available, as well as the recording time, are shown in the display.



A brief beep sounds when the recording starts. Now dictate the text.



Switch between pause/record.



End recording.

The recording is automatically saved with a time stamp.

Rename with **Options**.

## Playback



Select the desired recording.



Switch between playback/pause.



Press and **hold** for rapid rewind and fast forward.

## Dictating machine options

### Options

Open menu.

### Handsfree

Playback through the built-in loudspeaker.

(For standard functions see p. 16)

## Using the plus/minus key

(in standby mode)



Press and hold for the duration of the recording.



Press briefly to play back the most recent recording.




## Time zones




The time zone can be selected in the world map or a city list:

### World map



Select the desired time zone.

### City list




Select a city in the selected time zone.

## Time zone options

**Options** Open menu.

**Set** Specify the time zone.

**Auto time zone**  The time zone is switched automatically to local time by the network.

**Search city** Search for a city.

**Help** Operating instructions.


# Extras

## SIM services (optional)

 →  → SIM services

Your service provider may offer special applications such as mobile banking, share prices, etc. via the SIM card.

If you have such a SIM card, the SIM services will appear in the main menu under “Extras” or directly above the soft key (on the left).

 Symbol for SIM services.


Where there are several applications, these are displayed in a SIM services menu. With the SIM services menu, your phone can support future additions to your service provider's user package. For further information, please contact your service provider.

## Alarm clock

 →  → Alarm clock

The alarm will ring at the time set by you, even when the phone is switched off.

**Edit** Press to set.

 Activate/deactivate the alarm.

 Switch to time setting.



Set alarm call time (hh:mm).



Switch to week days.



Navigate to the various days.



Display options: alarm call time and days.



Set days for alarm calls. Press again to delete the highlighting.

Press and **hold** to highlight/unhighlight all the days.



Confirm setting.

### Additional information



Screen display in standby mode: alarm clock activated.

Use **Snooze** to set the alarm to repeat.

## Calc.



The calculator can be used in a basic version and with an advanced range of functions. The input line and two calculation lines (including the matrix with the calculation functions) are located in the top half of the display.



Enter digit(s).



Navigate functions.



Enter digit(s).



Use function. The result is calculated and displayed immediately.

### Basic functions

$+$ , $-$ , $*$ , $/$	Basic calculation types
$=$	Result
$1/x$	Reversion
$\%$	Convert to percentage
$.$	Decimal point.
$\pm$	Sign change “+”/“-”

### Options

#### Expansion of the range of functions:

$\sqrt{x}$	Square root
$x^2$	Square
$e$	Exponent
<b>MS</b>	Save displayed number
<b>MR</b>	Call up saved number
<b>M+</b>	Insert number from memory

## Calculator options

### Options

Open menu.

Convert	Call up the unit converter with the current result.
Clear all	Delete all units.
Extended mode/ Basic mode	Convert calculation functions.
Memory save, Memory recall, Memory clear	Save or recall result; delete memory.

(For standard functions see p. 16)

## Unit converter



You can convert various measurement units into other measurement units.

The following types are offered with various units:

Velocity

Energy

Mass

Pressure

Time

Volume

Area

Length

Power

Temperature

Currency

Example for Velocity units:

Type	Units
Velocity	Kilometres/h, Metres/sec, Miles/h, Miles/sec, Knots, Mach

### Converting the units/currency



Select the source unit/currency.



Switch to the input field.



Enter the quantity to be converted.



Switch to the selection field.



Select the target measurement unit/currency. The result is displayed.

You can use both input fields alternately.

Special key functions:



Set decimal point.



Change sign.

### Currency

When you call up the function, you must enter a base currency into which the conversions are to be made.



Enter currency (e. g. euro).




Store entry.

Now enter the name and exchange rate of the currency to be converted.



Open menu.



Enter new currency and exchange rate.



Use entered currency as base currency.



Change the exchange rate of the base currency.



Start calculator.



(For standard functions see p. 16)

## Stopwatch




Two intermediate times can be recorded and saved.

Display also in standby mode.



After a stop:



### Stopwatch options

**Options** Open menu.

**Stopwatch list** Display saved entries.

(For standard functions see p. 16)




## Countdown




A set time elapses. The last 3 seconds are indicated by a beep. At the end a special beep sounds.

Display also in standby mode.



If no time has been entered:



If a countdown time is specified:



While the time is elapsing:



**Reset** Reset counter to starting time.

## Sound recorder



For description, see p. 111

## Remote synchronisation



→ Remote syncr.

You can use this function remotely to access externally filed data (addresses, calendar, etc.) and synchronise these with the data on your phone. The data can, for example, be saved on a company computer or the Internet e.g.:

[www.siemens-mobile.com/syncml](http://www.siemens-mobile.com/syncml)

### Synchronising

#### Sync

The computer is selected and synchronisation started. When completed, the actions which have been performed are displayed.

#### Next

Scroll through the various displays.

### Sync. setting

The following settings can be made prior to synchronisation:

#### Sync. profile

You can choose between 5 profiles.



Select profile.



Activate profile.

Or

#### Edit

Set profile.

### Server sett.

Providers	Display the current service provider.
Homepage:	e.g. <a href="http://www.siemens-mobile.com/syncml">www.siemens-mobile.com/syncml</a>
Port:	Enter port number. e.g. 80.
Login:	Enter user name (login name).
Password:	Enter password (shown as a series of asterisks).
Calendar path	e.g. events
Contacts path	e.g. contacts
Notes path	e.g. notes
Task path	e.g. tasks
HTTP authentication:	Confirmation required; Yes/No (if No, the input fields are not visible).
HTTP name:	Enter name.
HTTP password:	Enter password.

**Last sync:**

Time of the last synchronisation.

**Sync. mode**

- **Sync data:** Modified data or All data
- **Sync direction:** Two-way, Mobile update or Server update

**Sync items:**

Highlight database areas to be synchronised:

Calendar

Addressbook

Notes

Tasks



Save settings.

**Device manag.**

→ Device manag.

If you were informed about software updates by a push message, you can establish a connection to the provider's server using the Device manager, so you can download them.

When downloading is finished, you will be asked to switch the phone off and on again. Afterwards, the software of your phone will be updated. Please follow instructions in the display.

The phone default setting varies from service provider to service provider:

- The settings have already been implemented by the service provider. You can start immediately.

- Access profiles have already been created by your service provider. Then select profile and activate.
- The access profiles must be configured manually. If necessary, contact your service provider. You will also find the current settings for the service provider on the Internet at [www.siemens.com/mobilephonescustomercare](http://www.siemens.com/mobilephonescustomercare) under "FAQ".

**Active profile**

A standard profile for downloading the current software of the operating system is displayed.

**Sync**

Establish a connection with the active profile.

Or

**Edit**

Call up profile list.



Select profile.



Activate profile.

Or

**Edit**

Set profile.

**Last connect.**

Display last connection.

# Sound recorder

Use the sound recorder to record noises and sounds for use as ringtones. The sound recorder is usually started from other applications/functions such as assigning a ringtone.

## New recording

### Starting from main menu



or also start from another application:

<Record new>

Select. The remaining time available, as well as the recording time, are shown in the display.



A brief tone sounds when the recording starts.



Switch between pause/record.



End recording.

The recording is saved with a timestamp in the **Sounds** folder. Rename with **Options**.

When starting from another application, e.g. Create MMS:

**Insert** Transfer the recording into the application.

## Playback



Select the desired recording.



Switch between playback/pause.



Press and **hold** for rapid rewind and fast forward.

### Options

Open menu.

Handsfree	Playback through the built-in loudspeaker.
Set as...	Set the recording as a ringtone.
(For standard functions see S. 16)	



# Media player


When you are viewing a picture/video or listening to a melody, the application starts a media playback.


 Press **briefly** to scroll to the next media file.


 Switch on display illumination.

## Pictures


The following functions can be applied to a displayed picture:


 Zoom function if the displayed picture has a higher resolution than the display.

 Use the plus/minus key to enlarge/reduce the size of the picture.

 The joystick moves the picture detail.


 Centre the picture.


 Switch to full screen mode and back again.

 Send via MMS or e-mail, for example.


## Melodies/video


The media playback offers the following functions for melody and video playback:

 Play or stop, depending on the situation.


 Set volume.

 Switch to mute.

 Pause function.

 End playback.

## Options

 Open menu.

Different functions are offered depending on the starting situation and the object.

<b>Volume</b>	Set the volume with the joystick.
<b>Set as...</b>	Set picture as <b>Wallpaper</b> , <b>Logo</b> , for example, and sounds, for example, for <b>Incoming call</b> , <b>Startup melody</b> .
<b>Slideshow</b>	Automatic run-through in full screen mode. Change individual picture with joystick.

(For standard functions see p. 16)

# My stuff

To organise your files, you can use the file system like a PC file manager. There are separate folders for the various data types in **My stuff**. The appropriate folders contain the download function for downloading new pictures and sounds, for example.

Please remember that pictures and sounds may be protected.



The list of the folders and files is displayed. The first entry in **My stuff** is always the RS MultiMediaCard™ (p. 114).

## Navigation



Select file/folder in lists.



The cursor can be moved as required in the preview.



Open folder, start download or start file with corresponding application.

# My stuff options

**Options** Open menu.

<b>Move</b>	Place highlighted file(s) or folder in temporary memory.
<b>Copy</b>	Place highlighted file(s) or folder in temporary memory.
<b>Paste</b>	Transfer content of temporary memory into current folder.
<b>New folder</b>	Create a new folder and name it.
<b>Thumbn. view/ List view</b>	Switch over to miniature view/view of list.
<b>Attributes</b>	Display information on file or folder selected.
<b>Format card</b>	Format inserted RS MultiMediaCard™.
<b>Eject card</b>	Allows the RS MultiMediaCard™ to be removed without loss of data.

(For standard functions see p. 16)

## Directory structure

Separate folders have already been created for different data types in **My stuff**. These folders cannot be changed.

Folder	Description	Format
MultiMedia Card	Access to the RS MultiMedia-Card	
Pictures	Pictures	bmp bmx jpg/jpeg png gif
Videos	Videos	3gp
Animations	Start up/shut down animations	bmx gif
Sounds	Melodies	mid amr wav
Themes	Loaded theme (zipped)	sdt
	Theme configuration (unzipped)	stc
Colour skins	Colour skins for user interface	scs
Games	Java archive	jar
	Download info	jad
Applications	Applications	*
Misc.	Text modules	tmo
	Voice recordings	vmc

Depending on the service provider, the structure, content and range of functions in **My stuff** may vary.

## RS MultiMediaCard™

The RS MultiMediaCard gives your phone a very large memory capacity. This allows you to save picture/video files, and sound recordings, for example. However, you can also use this memory card like a floppy disk to save any other files you may wish to save.



The list of the folders and files is displayed. The first entry is always **My stuff**.

The folders and files on the memory card are managed in the same way as in **My stuff**. If the memory card assigns a file to a function in the phone such as a ringtone, this is copied to **My stuff**.

### Additional information

**RS MultiMediaCard™** is a trademark of the MultiMediaCard Association.

### Changing the RS MultiMediaCard™ (p. 10)

#### New RS MultiMediaCard™

1. Create a backup copy of the data on the old memory card on a PC.
2. Format the new memory card.
3. Copy the data from the PC onto the new memory card.

# Mobile Phone Manager

The Windows® PC program, Mobile Phone Manager, enables you to use extended phone functions from your PC. For example, you can update your Addressbook in the phone, read, save and send SMS and MMS messages, or synchronise your phone with Outlook® or Lotus Notes™. The phone and PC communicate via a data cable (See Accessories, p. 125).



You can download the software from the Internet:

[www.siemens.com/sp65](http://www.siemens.com/sp65)

## Contacts management



You can use contacts management to manage the personal contacts you have stored in your phone, to add new ones and to delete and edit them. You can compare and copy contacts between your phone, Outlook®, Lotus Notes™ and other Siemens phones (including Gigaset).

## SMS and MMS management (messages)



Write MMS and SMS messages from the convenience of your PC. Use all the options your PC offers you and use your sounds and pictures to create MMS and EMS messages. You can read, forward, print, delete and archive your messages.

## Backing up and restore



With the back-up function, you can regularly make a back-up copy of your telephone data on the PC. If you ever lose the data on your phone or replace the phone, you can quickly re-instate all data with the restore function. Please observe any possible restrictions for DRM-protected data (p. 14).

## Bookmark management (browser & bookmarks)



Use your PC to browse through the Internet and define your preferred sites. Save the Internet addresses as bookmarks on your phone so that you can quickly call them up at a later time when you are on the move.

## Phone explorer



You can use the phone explorer to read your phone's file system. Files such as pictures, sounds and much more can easily be copied between the phone and PC by dragging and dropping.

## GPRS modem



The GPRS modem establishes an Internet connection via your mobile phone so that you can surf the Internet on your laptop while on the move and at the touch of a button.

## Processing pictures and photos (images)



Picture/photo processing offers the user the opportunity to conveniently create, edit and manage pictures and photos. Filters and effects are offered to help create colourful, attractive graphics. The user-friendly interface makes child's play of transferring pictures/photos from or to the mobile phone, and of changing the graphic settings.

## Ringtone management (sound)







The sound module allows the user to manage nearly all sound formats easily and to save them on the phone. This phone does not support MP3 functionality.


# Questions & Answers

If you have any questions on the use of your phone, you can contact us at [www.siemens.com/mobilephonescustomercare](http://www.siemens.com/mobilephonescustomercare) around the clock. As further help we have listed below some frequently asked questions and answers.

Problem	Possible causes	Possible solution
Phone cannot be switched on.	On/Off key not pressed long enough.	Press On/Off key for at least 2 seconds.
	Flat battery.	Charge battery. Check charging indicator in the display.
	Battery contacts dirty.	Clean contacts.
	See also below under "Charging error".	
Standby time is too short.	Frequent use of organiser and games.	Restrict use if applicable.
	Fast search activated.	Deactivate speed search (p. 94).
	Display illumination switched on.	Switch off display illumination (p. 77).
	Unintentional keystrokes (illumination!).	Activate key lock (p. 91).
Charging error (charge icon not displayed).	Battery totally discharged.	1) Plug in charger cable, battery is on charge. 2) Charge icon appears after approx. 2 hours. 3) Charge battery.
	Temperature out of range: +5 °C to +45 °C.	Make sure the ambient temperature is right, wait for a while, then recharge.
	Contact problem	Check power supply and connection to the phone. Check battery contacts and telephone connection socket, clean them if necessary, then insert battery again.
	No mains voltage.	Use different mains power socket, check mains voltage.
	Wrong charger.	Only use original Siemens accessories.
	Battery faulty.	Replace battery.
SIM error.	SIM card not inserted correctly.	Check that the SIM card is inserted correctly (p. 9).
	Dirty SIM card contacts.	Clean SIM card with a dry cloth.
	SIM card with wrong voltage.	Use 1.8 or 3 V SIM cards only.
	SIM card damaged (e.g. broken).	Carry out a visual check. Have service provider change the SIM card.

Problem	Possible causes	Possible solution
No network connection.	Weak signal. Outside GSM range. Invalid SIM card. New network not authorised. Network call barring is set. Network overloaded.	Move higher, to a window or an open space. Check service provider's coverage area. Complain to the service provider. Try manual selection or select a different network (p. 93). Check network barrings (p. 92). Try again later.
Phone loses network.	Signal too weak.	Reconnection to another service provider is automatic (p. 93). Switching phone off and on again can speed this up.
Calls not possible.	Second line set. New SIM card inserted. Charge limit reached. Credit used up.	Set first line  (p. 94). Check for new barrings. Reset limit with PIN2 (p. 40). Load credit.
Some calls not possible.	Call restrictions are in place.	Barrings can be set by service provider. Check barrings (p. 92).
Impossible to make entries in Phonebook/Addressbook.	Phonebook/Addressbook is full.	Delete entries in the Addressbook/Phonebook (see standard functions, p. 16).
Voice message not functioning.	Call divert to mailbox not set.	Set call divert to mailbox (p. 59).
 flashes to indicate an SMS.	SMS memory full.	Delete SMS messages (see standard functions, p. 16) or archive them (p. 44).
 flashes to indicate an MMS.	MMS memory full.	Delete MMS messages (see standard functions, p. 16).
 flashes to indicate an MMS.	Phone memory full.	Delete messages, pictures, videos, games or applications.
Function cannot be set.	Not supported by service provider or registration required.	Contact your service provider.
Capacity problems with, for example, Games & More, ring-tones, pictures, videos, SMS archive.	Phone memory full.	Delete files in the relevant areas. You can use the memory assistant to delete specific files (p. 82).
No Internet access; downloading not possible.	Profile not activated, profile settings wrong/incomplete.	Activate or set browser profile (p. 69). If necessary ask your service provider.

<b>Problem</b>	<b>Possible causes</b>	<b>Possible solution</b>
Text message cannot be sent.	Service provider does not support this service.	Contact your service provider.
	Phone number for service centre not set or incorrectly set.	Set service centre (p. 46).
	SIM card contract does not support this service.	Contact your service provider.
	Service centre overloaded.	Repeat message.
	Recipient does not have a compatible phone.	Check.
EMS pictures are not displayed on the destination phone.	Destination phone does not support the EMS standard.	
No Internet access possible.	Incorrect browser profile set, or wrong or incomplete settings.	Check browser settings (p. 69), or contact your service provider.
PIN error/ PIN2 error.	Three wrong entries.	Enter the PUK (MASTER PIN) supplied with the SIM card according to the instructions. If you have lost the PUK (MASTER PIN), contact your service provider.
Phone code error.	Three wrong entries.	Contact Siemens Service (p. 120).
Service provider code error.	No authorisation for this service.	Contact your service provider.
Too few/too many menu entries.	Functions may have been added or deleted by the service provider via the SIM card.	Check with your service provider.
No fax possible.	Wrong settings in the PC.	Check settings (p. 89).
	No authorisation for this service.	Contact your service provider.
Charge meter does not work.	Charge pulse is not being transmitted.	Contact your service provider.
<b>Damage</b>		
Severe shock.	Remove battery and SIM and re-insert them. Do not dismantle the phone!	
Phone became wet.	Remove battery and SIM. Dry immediately with a cloth, but do not apply heat. Dry connector contacts thoroughly. Stand mobile upright in an air current. Do not dismantle the phone!	

**Resetting all settings to factory default, p. 83: \*#9999#** 



# Customer Care

We offer fast, individual advice! You have several options:

Our online support on the Internet:

**www.siemens.com/  
mobilephonescustomer-care**

We can be reached any time, any place. You are given 24 hour support on all aspects of our products. Here you will find an interactive fault-finding system, a compilation of the most frequently asked questions and answers, plus user guides and current software updates to download.

When calling customer service, please have ready your receipt and the phone identity number (IMEI, to display press \*#06#, the software version (to display, press \*#06#, then **More**) and if available, your Siemens Service customer number.

You will also find the most frequently asked questions and answers in the section entitled "Questions & Answers" in this user guide on (p. 117).

You can also get personal advice about our range of products on our Premium Hotline:  
**United Kingdom ..... 0906 9597500**  
(0.75 £ per minute)

Qualified Siemens employees are waiting to offer you expert information about our products and installation.

In some countries repair and replace services are impossible where the products are not sold through our authorised dealers.

If repair work is necessary, please contact one of our service centres:

Abu Dhabi .....	0 26 42 38 00
Argentina .....	0 80 08 88 25 93
Australia .....	13 00 66 53 66
Austria .....	05 17 07 50 04
Bahrain .....	40 42 34
Bangladesh .....	0 17 52 74 47
Belgium .....	0 78 15 22 21
Bolivia .....	0 21 21 41 14
Bosnia Herzegovina .....	0 33 27 66 49
Brazil .....	0 80 07 07 12 48
Brunei .....	02 43 08 01
Bulgaria .....	02 73 94 88
Cambodia .....	12 80 05 00
Canada .....	1 88 87 77 02 11
Chile .....	8 00 53 06 62
China .....	0 21 23 01 71 88
Colombia .....	01 80 07 00 66 24
Croatia .....	0 16 10 53 81
Czech Republic .....	2 33 03 27 27
Denmark .....	35 25 86 00
Dubai .....	0 43 96 64 33
Ecuador .....	18 00 10 10 00
Egypt .....	0 23 33 41 11
Estonia .....	6 30 47 97
Finland .....	09 22 94 37 00
France .....	01 56 38 42 00
Germany .....	0 18 05 33 32 26
Greece .....	80 11 11 11 16
Hong Kong .....	28 61 11 18
Hungary .....	06 14 71 24 44
Iceland .....	5 11 30 00
India .....	22 24 98 70 00 Extn: 70 40
Indonesia .....	0 21 46 82 60 81
Ireland .....	18 50 77 72 77
Italy .....	02 24 36 44 00
Ivory Coast .....	05 02 02 59
Jordan .....	0 64 39 86 42
Kenya .....	2 72 37 17
Kuwait .....	2 45 41 78
Latvia .....	7 50 11 18
Lebanon .....	01 44 30 43

---

Libya .....	02 13 50 28 82	Russia .....	8 80 02 00 10 10
Lithuania .....	8 52 74 20 10	Saudi Arabia .....	0 22 26 00 43
Luxembourg .....	43 84 33 99	Serbia .....	01 13 07 00 80
Macedonia .....	02 13 14 84	Singapore .....	62 27 11 18
Malaysia .....	+ 6 03 77 12 43 04	Slovak Republic .....	02 59 68 22 66
Malta .....	+ 35 32 14 94 06 32	Slovenia .....	0 14 74 63 36
Mauritius .....	2 11 62 13	South Africa .....	08 60 10 11 57
Mexico .....	01 80 07 11 00 03	Spain .....	9 02 11 50 61
Morocco .....	22 66 92 09	Sweden .....	0 87 50 99 11
Netherlands .....	0 90 03 33 31 00	Switzerland .....	08 48 21 20 00
New Zealand .....	08 00 27 43 63	Taiwan .....	02 23 96 10 06
Nigeria .....	0 14 50 05 00	Thailand .....	0 27 22 11 18
Norway .....	22 70 84 00	Tunisia .....	71 86 19 02
Oman .....	79 10 12	Turkey .....	0 21 65 79 71 00
Pakistan .....	02 15 66 22 00	Ukraine .....	8 80 05 01 00 00
Paraguay .....	8 00 10 20 04	United Arab Emirates .....	0 43 66 03 86
Peru .....	0 80 05 24 00	United Kingdom .....	0 87 05 33 44 11
Philippines .....	0 27 57 11 18	USA .....	1 88 87 77 02 11
Poland .....	08 01 30 00 30	Venezuela .....	0 80 01 00 56 66
Portugal .....	8 08 20 15 21	Vietnam .....	84 89 20 24 64
Qatar .....	04 32 20 10	Zimbabwe .....	04 36 94 24
Romania .....	02 12 04 60 00		

## Care and maintenance

Your phone has been designed and crafted with great care and attention and should also be treated with care. The suggestions below will help you to enjoy your phone for many years.

- Protect your phone from moisture and humidity! Precipitation, humidity and liquids contain minerals that will corrode electronic circuits. Should your phone nonetheless become wet, disconnect it immediately from any power supply and/or remove the battery, and leave the open phone to dry at room temperature!
- Do not use or store the phone in dusty, dirty areas. Its moving parts may become damaged.
- Do not store your phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries and warp or melt certain plastics.
- Do not store your phone in cold areas. When the phone warms up again (to its normal ambient temperature), moisture can form inside the phone, which may damage electronic components.

- Do not drop, knock or shake your phone. Rough handling can damage components inside the device!
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone!

The suggestions given above apply equally to your phone, battery, charger and all accessories. If any of these parts are not working properly, take them to your nearest qualified service outlet. The personnel there will assist you and, if necessary, repair the device.

# Product data

## Declaration of conformity

Siemens Information and Communication mobile hereby declares that the phone described in this user guide is in compliance with the essential requirements and other relevant provisions of European Directive 1999/5/EC (R&TTE). The declaration of conformity (DoC) concerned has been signed. Please call the company hotline if you require a copy of the original or visit:

[www.siemens.com/mobiledocs](http://www.siemens.com/mobiledocs)

CE 0168

## Technical data

GSM class:	4 (2 watt)
Frequency range:	880–960 MHz
GSM class:	1 (1 watt)
Frequency range:	1,710–1,880 MHz
GSM class:	1 (1 watt)
Frequency range:	1,850–1,990 MHz
Weight:	85 g
Size:	119 × 48 × 18 mm (85 ccm)
Li-Ion battery:	800 mAh
Operating temp.:	–10 °C to +55 °C
SIM card:	1.8 or 3.0 V

### Phone ID

You will need the following information if you lose your phone or SIM card:

the number of the SIM card (on the card):

.....

15-digit serial number of the phone  
(under the battery):

.....

the customer service number of the service  
provider:

.....

### Lost phone

If you lose your phone or SIM card contact your service provider immediately to prevent misuse.

## Operating times

The operating time depends upon the respective conditions of use. Extreme temperatures considerably reduce the phone's standby time. Avoid placing the phone in the sun or on a heater.

**Talktime: 100 to 300 minutes**

**Standby time: 60 to 250 hours**

Action taken	Time (min)	Reduction of standby time by
Calling	1	30–90 minutes
Light *	1	40 minutes
Network search	1	5–10 minutes

\* Key input, games, organiser etc.

# Quality

## Battery quality declaration

The capacity of your mobile phone battery will reduce each time it is charged/discharged. Storage at too high or low temperatures will also result in a gradual capacity loss. As a result the operating time of your mobile phone may be considerably reduced, even after a full recharge of the battery.

Regardless of this, the battery has been designed and manufactured so that it can be recharged and used for six months after the purchase of your mobile phone. After six months, if the battery is clearly suffering from loss of performance, we recommend that you replace it. Please buy only Siemens original batteries.

## Display quality declaration

For technological reasons, some small dots in other colours may appear in the display in rare cases.


Please remember that if some dots appear brighter or darker in the display, this generally does not mean that a fault has occurred.

# Accessories

## Fashion & Carry

### Carrying Cases

A range of carry cases is available at specialist shops or you can visit the Siemens Mobile Store online at:



## Energy

### Li-Ion Battery (750 mAh) EBA-660

Spare battery

### Travel Charger

Travel Charger EU ETC-500

Travel Charger UK ETC-510

Travel charger with an extended input voltage range of 100–240 V.

### Car Charger Plus ECC-600

Charger for the cigarette lighter socket in the car. It is possible to make phone calls during charging.

## Handsfree portable

### Headset Basic HHS-500

Simple headset without PTT key

### Headset HHS-510

Headset with PTT key to accept and end calls.

### Headset Purestyle HHS-610

High quality headset with removable ear-piece and PTT key.

### Bluetooth® Headset

HHB-600 with EU power supply unit

HHB-610 with UK power supply unit

HHB-620 with Australian power supply unit

Elegant, small, easy to wear

Bluetooth® headset.

## Office

### Data Cable DCA-500

For connecting the phone to the serial RS232 port of the PC.

### Data Cable USB DCA-540

For connecting the phone to the USB port of the PC. With charging function.

## Car Solutions

### Mobile Holder Antenna HMM-670

The cradle for connecting an external antenna. Ideal for use with headset PTT or car kit portable.

Can also be used as cradle for retrofitting your handsfree car kit (series 55).

### Car Kit Comfort HKC-670

Handsfree kit with first-class digital call quality and supreme ease of use. Includes all components needed for installation. The individual antenna solution is available in specialist shops.

### Car Kit Easy HKP-600

Facilitates convenient handsfree talking with high call quality. With the integrated, rotating cradle and the flexible microphone positioning, the telephone can be optimally adjusted to suit any vehicle interior. The power is supplied via the cigarette lighter socket.

### Car Kit Bluetooth® HKW-600

Innovative Bluetooth handsfree kit with an external display for making in-car calls safely and conveniently.

### Optional car kit accessories

Car Data Adapter HKO-690

Phone-In-Adapter Cable HKO-570

Products can be obtained in specialist shops or you can visit the Siemens Mobile Store online:



Siemens Original Accessories

[www.siemens.com/shop](http://www.siemens.com/shop)

## Guarantee certificate (UK)

Without prejudice to any claim the user (customer) may have in relation to the dealer or retailer, the customer shall be granted a manufacturer's Guarantee under the conditions set out below:

- In the case of new devices and their components exhibiting defects resulting from manufacturing and/or material faults within 24 months of purchase, Siemens shall, at its own option and free of charge, either replace the device with another device reflecting the current state of the art, or repair the said device. In respect of parts subject to wear and tear (including but not limited to, batteries, keypads, casings, small parts on casings, protective coverings where included in the scope of delivery), this warranty shall be valid for six months from the date of purchase.
- This Guarantee shall be invalid if the device defect is attributable to improper treatment and/or failure to comply with information contained in the user manuals.
- This Guarantee shall not apply to or extend to services performed by the authorised dealer or the customer themselves (e.g. installation, configuration, software downloads). User manuals and any software supplied on a separate data medium shall be excluded from the Guarantee.
- The purchase receipt, together with the date of purchase, shall be required as evidence for invoking the Guarantee. Claims under the Guarantee must be submitted within two months of the Guarantee default becoming evident.
- Ownership of devices or components replaced by and returned to Siemens shall vest in Siemens.
- This Guarantee shall apply to new devices purchased in the European Union. For Products sold in the United Kingdom the Guarantee is issued by Siemens plc, Siemens House, Oldbury, Bracknell, Berkshire, RG12 8FZ.
- Any other claims resulting out of or in connection with the device shall be excluded from this Guarantee. Nothing in this Guarantee shall attempt to limit or exclude a Customers Statutory Rights, nor the manufacturer's liability for death or personal injury resulting from its negligence.
- The duration of the Guarantee shall not be extended by services rendered under the terms of the Guarantee.



- Insofar as no Guarantee default exists, Siemens reserves the right to charge the customer for replacement or repair.
- The above provisions does not imply a change in the burden of proof to the detriment of the customer.

To invoke this Guarantee, please contact our online support on the Internet

**[www.siemens.com/](http://www.siemens.com/)**

**mobilephonescustomercare**

or the Siemens telephone service.

The relevant number is to be found in the accompanying user guide.

## Guarantee certificate (IRL)

Without prejudice to any claim the user (customer) may have in relation to the dealer or retailer, the customer shall be granted a manufacturer's Guarantee under the conditions set out below:

- In the case of new devices and their components exhibiting defects resulting from manufacturing and/or material faults within 24 months of purchase, Siemens shall, at its own option and free of charge, either replace the device with another device reflecting the current state of the art, or repair the said device. In respect of parts subject to wear and tear (including but not limited to, batteries, keypads, casings, small parts on casings, protective coverings where included in the scope of delivery), this warranty shall be valid for six months from the date of purchase.
- This Guarantee shall be invalid if the device defect is attributable to improper care or use and/or failure to comply with information contained in the user manuals. In particular claims under the Guarantee cannot be made if:
  - The device is opened (this is classed as third party intervention)
  - Repairs or other work done by persons not authorised by Siemens.
- Components on the printed circuit board are manipulated
- The software is manipulated
- Defects or damage caused by dropping, breaking, lightning or ingress of moisture. This also applies if defects or damage was caused by mechanical, chemical, radio interference or thermal factors (e.g.: microwave, sauna etc.)
- Devices fitted with accessories not authorised by Siemens
- This Guarantee shall not apply to or extend to services performed by the authorised dealer or the customer themselves (e.g. installation, configuration, software downloads). User manuals and any software supplied on a separate data medium shall be excluded from the Guarantee.
- The purchase receipt, together with the date of purchase, shall be required as evidence for invoking the Guarantee. Claims under the Guarantee must be submitted within two months of the Guarantee default becoming evident.
- Ownership of devices or components replaced by and returned to Siemens shall vest in Siemens.

- This Guarantee shall apply to new devices purchased in the European Union. For Products sold in the Republic of Ireland the Guarantee is issued by Siemens Ireland Limited, Ballymoss Road, Sandyford Industrial Estate, Dublin 18 - The Republic of Ireland.
- Any other claims resulting out of or in connection with the device shall be excluded from this Guarantee. Nothing in this Guarantee shall attempt to limit or exclude a Customers Statutory Rights, nor the manufacturer's liability for death or personal injury resulting from its negligence.
- The duration of the Guarantee shall not be extended by services rendered under the terms of the Guarantee.
- Insofar as no Guarantee default exists, Siemens reserves the right to charge the customer for replacement or repair.
- The above provisions does not imply a change in the burden of proof to the detriment of the customer.

To invoke this Guarantee, please contact our online support on the Internet

**[www.siemens.com/](http://www.siemens.com/)**

**[mobilephonescustomer-care](http://www.siemens.com/mobilephonescustomer-care)**

or the Siemens telephone service.

The relevant number is to be found in the accompanying user guide.

# SAR – European Union (RTTE)

## INFORMATION ON RF EXPOSURE/ SPECIFIC ABSORPTION RATE (SAR)

THIS MOBILE PHONE COMPLIES WITH THE LIMIT VALUES PRESCRIBED BY THE EU (1999/519/EC) FOR PROTECTING THE PUBLIC FROM THE EFFECTS OF EXPOSURE TO ELECTROMAGNETIC FIELDS. FOR THIS REASON, THE PHONE SHOULD BE POSITIONED AT LEAST 1.5 CM AWAY FROM THE BODY WHEN DATA IS BEING TRANSFERRED (GPRS).

These limits are part of comprehensive recommendations for the protection of the public. The recommendations were developed and confirmed by independent scientific organisations through periodic and thorough evaluation of scientific studies\*. The limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

Before a radio equipment may be placed on the market, compliance with the European laws and the respective technical limit requirements must be demonstrated. Only then the CE mark may be affixed\*\*. The limit for mobile phones recommended by the Council of the European Union employs a unit of measurement known as the Specific Absorption Rate, or SAR. This SAR limit is 2.0 W/kg\*\*\*. This corresponds with the requirements of the

International Commission for Non-ionizing Radiation Protection ICNIRP and was adopted into the European Norm for Mobile Radio Equipment EN 50360. The SAR of mobile phones is determined in accordance with the European Norm EN 50361. This involves measuring the maximum value in all frequency bands of the mobile phone with the phone transmitting at its highest power level. The actual SAR level of the phone during normal operation may be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output.

The highest SAR value for this phone model when tested for compliance against the standard was  
0.36 W/kg\*\*\*\*.

You can also find the SAR value for this device on the Internet at this address

**[www.siemens.com/mobilephones](http://www.siemens.com/mobilephones)**.

While there may be differences between the SAR levels of various phones and at various positions, all Siemens products meet the legal requirements.

- \* The World Health Organization (WHO, CH-1211 Geneva 27, Switzerland) states that present scientific information does not indicate the need for any special precautions for use of mobile phones.

Further information:

**[www.who.int/peh-emf](http://www.who.int/peh-emf),**

**[www.mmfa.org](http://www.mmfa.org),**

**[www.siemens.com/mobilephones](http://www.siemens.com/mobilephones)**

- \*\* The CE mark confirms that the product is in compliance with the legal requirements of the European Union as a prerequisite for the placing on the market and the free movement of goods within the European internal market.

\*\*\* averaged over 10 g body tissue.

- \*\*\*\* SAR values may vary depending on national requirements and frequency bands. SAR information for different regions can be found at **[www.siemens.com/mobilephones](http://www.siemens.com/mobilephones)**

# SAR – International (ICNIRP)

## INFORMATION ON RF EXPOSURE/ SPECIFIC ABSORPTION RATE (SAR)

THIS MOBILE PHONE COMPLIES WITH THE LIMIT VALUES FOR PROTECTING THE PUBLIC FROM THE EFFECTS OF EXPOSURE TO ELECTROMAGNETIC FIELDS. FOR THIS REASON, THE PHONE SHOULD BE POSITIONED AT LEAST 1.5 CM AWAY FROM THE BODY WHEN DATA IS BEING TRANSFERRED (GPRS).

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) energy recommended by international guidelines from the International Commission on Non-ionizing Radiation Protection (ICNIRP). These limits are part of comprehensive guidelines for the protection of the public and establish permitted levels of RF energy for the population. The guidelines were confirmed by independent scientific organisations through periodic and thorough evaluation of scientific studies\*. The limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure limit for mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit stated in the international guidelines is 2.0 W/kg\*\*. Tests for SAR are conducted in all frequency bands using

standard operating positions with the phone transmitting at its highest power level. The actual SAR level of the phone during operation can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output.

The highest SAR value for this model phone when tested for use at the ear is

0.36 W/kg\*\*\*.

SAR information can also be found at [www.siemens.com/mobilephones](http://www.siemens.com/mobilephones). While there may be differences between the SAR levels of various phones and at various positions, they all meet the international guidelines for safe RF exposure.

\* The World Health Organization (WHO, CH-1211 Geneva 27, Switzerland) states that present scientific information does not indicate the need for any special precautions for use of mobile phones.

Further information:

[www.who.int/peh-emf](http://www.who.int/peh-emf),


[www.mmfa.org](http://www.mmfa.org),


[www.siemens.com/mobilephones](http://www.siemens.com/mobilephones)

\*\* averaged over 10 g of tissue.


\*\*\* SAR values may vary depending on national requirements and frequency bands. Information for different regions can be found at [www.siemens.com/mobilephones](http://www.siemens.com/mobilephones)


# Menu tree

















# Index

- A**
- Accessories..... 125
  - Addressbook
    - Dial entry..... 34
    - Groups ..... 35
    - New entry..... 32
    - Reading entry ..... 34
  - Aircraft mode ..... 74
  - Alarm
    - Alarm clock..... 105
    - Type ..... 101
  - Alarm clock ..... 105
  - All calls (diversion) ..... 81
  - All incoming (barrings) ..... 92
  - Answering service (external)..... 59
  - Any key to answer ..... 81
  - Appointments ..... 100
  - Authentication ..... 90
  - Auto display
    - Clock ..... 84
    - Duration/charges ..... 40
  - Auto key lock..... 91
  - Auto time zone..... 84, 104
  - Auto. network dialling ..... 93
  - Auto. redial ..... 25
  - Automobile accessories ..... 126
- B**
- Band selection ..... 94
  - Battery
    - Charge..... 11
    - Inserting..... 9
    - Operating times..... 12, 123
    - Quality Declaration ..... 124
  - Big letters ..... 77
  - Bluetooth® ..... 86
  - Bookmarks (WAP) ..... 68, 70
  - Browser ..... 69
  - Buddh. year ..... 84
  - Business card ..... 31
  - Busy number..... 25
- C**
- Calculator ..... 106
  - Calendar ..... 99
  - Call
    - Accepting/ending ..... 26
    - Barring ..... 92
    - Charges..... 40
    - Conference ..... 27
    - Diverting ..... 80
    - Ending ..... 24
    - Hold ..... 26
    - Menu ..... 28
    - Reject..... 26
    - Swap between calls  
(change)..... 26
  - Call back ..... 25
  - Call divert ..... 80
  - Call screening ..... 81
  - Call transfer ..... 28
  - Call waiting..... 27, 80
  - Calling ..... 24
  - Calls dialled (call record) ..... 39
  - Calls received (call record)..... 39
  - Car Kit
    - Accessories ..... 126
    - Setting ..... 95
  - Car kit accessories ..... 126
  - Care of phone ..... 122
  - Cell Broadcast (CB) ..... 67
  - Charges ..... 40
  - Charges/units..... 40
  - Charging the battery ..... 11

Clock .....	84
Colour skin .....	76
Conference.....	27
Connection profiles .....	88
Connectivity .....	85
Contact list .....	61
Control code (DTMF) .....	29
Converter .....	107
Countdown .....	108
Credit limit .....	40
CSD settings .....	89
Currency converter .....	107
<b>D</b>	
Date format.....	84
Default book .....	31
Dialling code .....	24
Dialling with number keys .....	24
Dictating machine .....	103
Digital Rights Management.....	14
Direct reply (SMS).....	46
Display	
Illumination .....	77
Language .....	76
Symbols.....	7
Wallpaper image.....	76
Divert .....	80
Download .....	71
DTMF tones	
(tone sequences).....	29
Duration/charges .....	40
<b>E</b>	
E-mail	
Lists.....	57
Settings .....	58
Writing .....	56
Emergency number .....	13
Extras.....	105, 111

**F**

Fast access.....	97
Fast network search .....	94
Fax/data mode .....	89
Formatting (phone memory) .....	83
Formatting (SMS text).....	42
Forwarding (call).....	28
Frequency range .....	94

**G**


Games and applications .....	71
GPRS.....	85
Groups.....	35
Guarantee certificate .....	127

**H**

Handset volume.....	24
Handsfree talking.....	26
Headset	
Accessories .....	125
Setting .....	95
Hide ID .....	80
Highlighting mode .....	17
Hold call .....	26, 28
Home network.....	93
Hotline .....	120
HTTP profile .....	89

**I**

Identity number (IMEI) .....	82
IMEI number .....	82
Inbox.....	41
Info tones .....	82
Information services (CB) .....	67
Infrared (IrDA) .....	85
Input language (T9) .....	21
Inst. Message.....	60
International dialling code.....	25
Internet .....	68

- J**  
Joystick ..... 5
- K**  
Key tones ..... 82
- L**  
Language ..... 76  
Limit (duration/charges) ..... 40  
Logo..... 76  
Loss of phone, SIM card ..... 123
- M**  
Mailbox ..... 59  
Maintenance of phone..... 122  
Master reset ..... 83  
Media player ..... 112  
Memory assistant ..... 82  
Menu  
    Controls..... 15  
    My menu ..... 96  
    Speed dialling ..... 17  
Menu speed dialling ..... 17  
Menu tree ..... 134  
Message  
    CB ..... 67  
    E-mail..... 56  
    MMS..... 48  
    SMS..... 42, 44  
Message memory full. .... 47  
Message type ..... 46  
Microphone on/off..... 28  
Minute beep..... 81  
Missed appointments ..... 102  
Missed calls (call record) ..... 39  
MMS  
    Lists..... 53  
    Receiving..... 52  
    Sending ..... 51  
    Writing ..... 48  
Mobile Phone Manager ..... 115  
MultiMediaCard ..... 114  
Muting (microphone)..... 28  
My items..... 30  
My menu ..... 96  
My stuff ..... 113
- N**  
Network  
    Barring ..... 92  
    Connection ..... 93  
    Settings ..... 93  
Notes..... 102
- O**  
One number only ..... 28  
Only  ..... 91  
Operating times  
(battery) ..... 12, 123  
Organiser..... 99  
Own (phone) numbers..... 38  
Own greeting..... 77
- P**  
Phone code..... 18  
Phone data ..... 123  
Phone identity number  
(IMEI) ..... 82  
Phone number memo ..... 25  
Phone number  
transmission on/off ..... 80  
Phone setup..... 82  
Phonebook  
    Calling an entry ..... 37  
    New entry ..... 36  
    Protected SIM..... 38  
    Special books ..... 38  
    VIP numbers..... 38  
Pictures & sounds (SMS)..... 43

- PIN
  - Changing..... 18
  - Control..... 18
  - Entering ..... 13
  - Error..... 119
- PIN2..... 18
- Preferred network..... 93
- Preventing accidental activation..... 19
- Product data..... 123
- Profiles
  - MMS..... 54
  - Phone..... 73
  - SMS..... 46
  - WAP ..... 70
- Prompt..... 25
- Provider logo..... 76
- PUK, PUK2..... 18
- Q**
- Questions & Answers..... 117
- R**
- Records..... 39
- Redial..... 24
- Reminder ..... 25
- Remote synchronisation ..... 109
- Ringtone setting..... 78
- Ringtones..... 35, 78
- S**
- Safety precautions..... 3
- Screensaver..... 76
- Second phone number ..... 93
- Security..... 18
- Security codes ..... 18
- Service centre (SMS)..... 46
- Service provider portal..... 30
- Service tones..... 82
- Setting time/date..... 84
- Settings..... 73
- Short message (SMS)..... 42
- Shown in the display..... 7
- Shut down animation..... 77
- Siemens City Portal ..... 30
- Signal strength ..... 14
- Silent alert ..... 78
- SIM card
  - Clearing barring ..... 19
  - Inserting ..... 9
  - Problems..... 117
- SIM services (optional) ..... 105
- SMS
  - Archive ..... 45
  - Lists ..... 45
  - Profiles..... 46
  - Read ..... 44
  - Settings ..... 46
  - Signature ..... 46
  - T9 input ..... 21
  - To group ..... 43
  - Writing..... 42
- Software version..... 82
- SOS ..... 13
- Sound recorder ..... 111
- Special books..... 38
- Special characters ..... 20
- Speech time (battery) ..... 123
- Speed dialling keys..... 98
- Standard functions..... 16
- Standby mode ..... 14
- Standby time ..... 12, 123
- Start up animation ..... 77
- Stopwatch ..... 108
- Storage location (Phonebook)..... 36
- Surf & fun ..... 68
- Swap ..... 26
- Switching off phone
  - Automatic..... 82
  - Manually..... 13



Switching on phone ..... 13  
Symbols ..... 7  
Synchronisation..... 109

**T**

T9 text input..... 21  
Tasks ..... 101  
Technical data ..... 123  
Text entry  
    With T9..... 21  
    Without T9 ..... 20  
Text module ..... 23  
Themes ..... 75  
This SIM only ..... 91  
Time zones..... 13, 84, 104

**U**

Unanswered ..... 80  
Upper and lowercase  
letters (T9) ..... 20  
User group ..... 94

**V**

Validity (SMS) ..... 46  
Video playback..... 112  
Voice message (mailbox) ..... 59  
Volume  
    Handset volume ..... 24  
    Profiles..... 73  
    Ringtone ..... 78

**W**

Wallpaper (display) ..... 76  
WAP push ..... 41