

JVC



Digital Camera

GC-A70



INSTRUCTIONS

Thank you for purchasing this JVC product. Before beginning to operate this unit, please read the instruction manual carefully in order to make sure that the best possible performance is obtained. If you have any question, consult your JVC dealer.

[To HomePage of JVC](#)

“ SOME DO'S AND DON'TS ON THE SAFE USE OF EQUIPMENT ”

This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured.

Do
read the operating instructions before you attempt to use the equipment.

Do
ensure that all electrical connections (including the mains plug, extension leads and inter-connections between pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug when making or changing connections.

Do
consult your dealer if you are ever in doubt about the installation or operation or safety of your equipment.

Do
be careful with glass panels or doors on equipment.

DON'T
continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way—switch off—withdraw the mains plug and consult your dealer.

DON'T
remove any fixed cover as this may expose dangerous voltages.

DON'T
leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a standby mode. Switch off using the switch on the equipment and make sure that your family know how to do this. Special arrangements may need to be made for infirm or handicapped people.

DON'T
use equipment such as personal stereos or radios so that you are distracted from the requirements of road safety. It is illegal to watch television when driving.

DON'T
listen to headphones at high volume as such use can permanently damage your hearing.

DON'T
obstruct the ventilation of the equipment, for example with curtains or on soft furnishings. Overheating will cause damage and shorten the life of the equipment.

DON'T
use makeshift stands and NEVER fix legs with wood screws. To ensure complete safety always fit the manufacturer's approved stand or legs with the fixing screws supplied according to the instructions.

DON'T
allow electrical equipment to be exposed to rain or moisture.

ABOVE ALL
NEVER let anyone especially children push anything into holes, slots or any other opening in the case. This could result in a fatal electrical shock.
NEVER guess or make changes with electrical equipment of any kind. It is better to be safe than sorry!



FCC INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not approved by JVC could void user's authority to operate the equipment.

Contact

**Address: JVC AMERICAS CORP.,
1700 Valley Road, Wayne, New Jersey 07470
Telephone: (973) 317-5000**

INFORMATION (for CANADA)

This Class B digital apparatus complies with Canadian ICES-003.


RENSEIGNEMENT (Pour le CANADA)

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.



WARNING:

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

SAFETY PRECAUTIONS

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**CAUTIONS****About moisture condensation . . .**

You may have observed that pouring a cold liquid into a glass will cause drops of water to form on the glass' outer surface. This same phenomenon occurs on the lens of the camera when it is moved from a cool place to a warm place, after heating a cold room, under extremely humid conditions or in a place directly subjected to the cool air from an air conditioner.

Serious malfunctioning

If malfunctioning occurs, immediately stop using the unit and remove the battery, then consult your local JVC dealer.

MAIN UNIT**1. For safe use, please do NOT . . .**

- ...open the camera's chassis due to high voltage inside.
- ...disassemble or modify the unit.
- ...allow inflammables, water or metallic objects to enter the unit.

...remove the batteries while the power is on.

...look through the viewfinder directly at the sun or extremely bright light.

...point the lens directly into the sun. This can lead to malfunctioning of the internal circuitry. There is also a risk of fire or electric shock.

...subject it to shock or excessive vibration.

...connect any USB cable to this unit except the one provided.

2. Avoid using the unit in the following places:

- Where the camera will be subject to dust, soot, steam, or excessive heat.
- Where the camera will be subject to excessive shock or vibration.
- Where the camera will be subject to extremely low (under 0°C or 32°F) or extremely high (over 40°C or 104°F) temperatures.
- In direct sunlight.
- In a closed car in summer.
- Near a heater.
- Near a television set.
- Near appliances generating strong magnetic or electric fields (speakers, broadcasting antennas, etc.).

3. To protect the unit, DO NOT . . .

...allow it to become wet.

...drop the unit or strike it against hard objects.

...subject it to shock or excessive vibration during transportation.

...keep the lens directed at extremely bright objects for long periods.

...swing it excessively when using the hand strap or neck strap.

MEMORY CARDS

1. To properly use and store your memory cards, be sure to read the following cautions:

- Make sure the memory card bears the SD or Multimedia Card mark.
- Make sure the memory card is positioned properly when inserting.
- While the memory card is being accessed (during recording, playback, deletion, formatting etc.), never unload the memory card or turn off the digital camera.
- Store memory cards...
 - ...away from heaters or other heat sources.
 - ...out of direct sunlight.
 - ...where they will not be subject to unnecessary shock or vibration.
 - ...where they will not be exposed to strong magnetic fields (such as those generated by motors, transformers or magnets).

LCD MONITOR

- To prevent damage to the LCD monitor, do NOT subject it to undue force or shocks.
- To prolong its service life, avoid rubbing it with a coarse cloth.

ALKALINE BATTERIES

1. For safe use, do NOT . . .

...attempt to charge the alkaline batteries.

...reverse the polarities of the batteries.

...carry or store a battery together with objects such as metal pens, necklaces, coins or hairpins. This could short-circuit the positive and negative poles of the battery.

...heat or attempt to disassemble a battery.

...expose the battery to water or fire.

...subject a battery to strong impacts, such as hitting it with a hammer, stepping on it or dropping it.

...forget to remove the batteries from the unit if the camera is not to be used for an extended period of time, so as to prevent leakage.

Any of these may cause the battery to split or leak, causing fire or injury.

2. Use only the specified batteries with this camera. The use of other power sources may cause a fire.

- 3. When discarding batteries, environmental problems must be considered and the local rules or laws governing the disposal of these batteries must be followed strictly.**

HOW TO HANDLE A CD-ROM

- Take care not to soil or scratch the mirror surface (opposite to the printed surface). Do not write anything or put a sticker on either the front or back surface. If the CD-ROM gets dirty, gently wipe it with a soft cloth outward from the center hole using a circular motion.
- Do not use conventional disc cleaners or cleaning spray.
- Do not bend the CD-ROM or touch its mirror surface.
- Do not store your CD-ROM in a dusty, hot or humid environment. Keep it away from direct sunlight.

FLASH

- Do not fire the flash at a person, particularly an infant, at short range for this may cause impairment of eyesight.
- Do not touch light-emitting portion after flash. This may cause burn.

BEFORE USING THE CAMERA

- We recommend that you take some test shots before you actually start, to accustom yourself to the camera.
- We cannot bear any responsibility for an inability to shoot, record, or play back material normally in the event of a problem with this camera.
- We shall not be liable for any incidental, consequential or exemplary damage, loss of profits or any demand made by any third party due to your use of this product or the provided software.
- Store backups of important images/video clips on a personal computer, etc. We cannot bear any responsibility for pictures stored in memory that are lost or altered.
- It is prohibited to use still images/video clips taken with this camera for commercial purposes without the consent of the copyright owner.
- Please be aware that the shooting subject may appear whitish or halation may occur in following conditions:
 - When a very bright subject is taken in a short distance.
 - When a subject which has a very bright part is taken in strong sunlight.

Notes:

- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Other trademarks are the properties of their respective owners.



FUN THINGS YOU CAN DO

This camera is an all-in-one compact size digital and USB PC-camera. With it, you can:

- Take digital pictures/video clips in an instant.
Easily capture digital images and download them to your computer.
- Videoconference on the Internet.
Keep in touch with distant family and friends. See and talk with people on the Internet face-to-face.
- Send captured images with your e-mail messages.



WHAT'S INCLUDED?

Please check to see that the following items are included in the package. If any item is missing, please enquire at your nearest JVC-authorized dealer.



Digital Camera GC-A70

CD-ROM with Driver,
Application & Instructions


USB Cable



Hand Strap



Neck Strap

Quick Start Guide
(5 Sheets, 9 Languages)

Caution Sheet

Notes:

- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Other trademarks are the properties of their respective owners.



SYSTEM REQUIREMENTS (PC)

- Microsoft® Windows® 98/98SE/Me/2000/XP (Pre-installed Model)
- Intel® Pentium® Processor 166 MHz or higher
- Free USB Port
- Minimum RAM: 32 MB (Windows XP: 128 MB)
- 250 MB of available hard disk space
- Color display: 800x600 or better
- CD-ROM drive

Notes:

- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Other trademarks are the properties of their respective owners.



FEATURES**LCD Monitor**

A 1.5-inch color TFT LCD monitor with high image quality of 2 megapixels that enables monitoring of images while shooting, and immediately after recording.

Design

Features a compact, posh metallic design.

Digital Zoom

Digital zooming of x2, x3 and x4 and macro mode (switching by lens) with a 45 cm close-up capability for wide variety of shooting scenes.

Multipurpose

A Digital Still Camera, usable as a movie camera (Video Clip: AVI w/o Sound) or Webcam as well as a Multi Digital Camera.

Built-in Digital Memory

Equipped with built-in 8 MB flash memory (that retain images even in the absence of a power supply) and SD/MMC compatible memory slot, the number of images can be increase simply by adding memory card.



Power Supply

Supplied by easily purchased AA-size alkaline batteries (x2, option). In addition, it operates with USB power source when connected to a PC through a USB port (i.e. when transferring images from the built-in memory to the PC or using as a Webcam).



GETTING TO KNOW THE CAMERA

Controls, Connectors and Indicators




GETTING STARTED

Be sure to insert the (AA-size Alkaline) batteries before trying to capture images with your camera.

Inserting the Batteries

1. Slide the Battery/Memory card compartment door (located on the right side of the camera) in the direction indicated by the arrow to open it.
2. Insert the AA-size batteries as indicated on the inner side of the door.
3. Close back the door and turn on the camera.



Checking Batteries(: Full battery power)

The Battery Indicator will be displayed on the status LCD monitor while the camera is on. Depending on the durability and usage of the batteries, the number of pictures that can be recorded varies. Note that power is consumed by the following operations even when not recording, reducing the number of images that can be recorded.

- Extensive use of the LCD monitor in the Play/Erase mode.
- Performing settings.



- | | |
|---|---|
|  | Battery Life > 40% |
|  | 20% < Battery Life < 40% |
|  | 10% < Battery Life < 20% |
|  | Battery Life < 10%.
Status Led flashes for 5 sec and then power off. |

Notes:

- Please ensure that the batteries are inserted in the correct way. Do not reverse the ⊕ and ⊖ polarities.
- The recommended battery type is AA size ALKALINE.
- Never use manganese batteries.
- Low temperatures (under 0°C or 32°F) will reduce the output efficiency of the batteries, thereby shortening the operation time of the camera.
- The use of Flash is not recommended when the battery level is low.
- Never mix old and new batteries.
- Remove the batteries if the camera is not to be used for an extended period of time, to prevent leaks or corrosion.
- Before discarding batteries, cover the positive ⊕ and negative ⊖ terminals with adhesive tape.
- The Battery Indicator reflects the level of remaining battery power. When the indicator appears as shown above, the batteries are weak and need to be replaced.

Attaching the Hand Strap or Neck Strap

Always use the provided hand strap or neck strap when carrying the camera. Please note that the company cannot be held responsible for any accidental drop of the camera due to improper use of the hand strap or neck strap.

To attach the strap to your camera:

1. Thread the thinner looped end of the strap through the strap holder.
2. Insert the other end of the strap through the thin loop and pull it all the way out. Ensure that the strap is securely tightened unto the camera.



Note:

- Be careful not to bump the camera or entangle the strap.

Inserting and Removing the SD / Multimedia Card

This camera can be used with either an SD card or a Multimedia card (MMC).

When traveling and capturing a lot of images, it is convenient to make use of an SD or a Multimedia card. When a card is inserted into the camera, still images/video clips captured will be stored in the card's memory.

When the card is removed, the camera's internal memory will be used as the storage media.

Inserting the Memory Card

1. Turn off the camera's power by pressing the [POWER] button.
2. Open the Battery/Memory card compartment door.
3. Firmly insert the memory card into the memory card slot as far as it can go, with the memory card electrodes (metal contacts) end facing the camera. (Refer to the right figure.)
4. Close back the door firmly.



Removing the Memory Card

1. Turn off the camera's power by pressing the [POWER] button.
2. Open the Battery/Memory card compartment door.
3. Push the memory card in as far as it can go and release. The card will spring back and protrude slightly. Pull it out with your fingers.
4. Close back the door firmly.


Notes:

- SD and Multimedia cards are purchased separately.
- Pay attention to the card direction when inserting. Wrong direction and forced insert can break it.
- When the memory card is inserted, access to the camera's internal memory is not possible.
- Cards available in the market, and those already formatted for PC and other devices may not be identified by this camera. Therefore, before using them, it is necessary to **format** them first with this camera.
- While the power of the camera is on, do not open the battery cover to replace the memory card or batteries as this may cause irrecoverable corruption of card data.
- The memory card is a sensitive device so it should not be subject to any shock. Do not touch the metal part of the card with your hand.
- When the memory card is write-protected, it cannot be used (A message "WRITE PROTECT" will appear on the LCD monitor). You have to disable the write-protection first.

Switching the Power ON / OFF


Press the [POWER] button to toggle ON / OFF.

The Status Indicator will lit up immediately upon power on. The light will go off after a while (the length of time varies with the capacity of the memory card that is inserted in the camera) and the camera will then be ready for use.



Switching the LCD Monitor ON / OFF

The LCD monitor is automatically activated when the power is switched on. However, since the LCD monitor consumes battery power fast, we recommend that you turn off the LCD monitor and use the optical viewfinder as far as possible when capturing still images. To switch the LCD monitor ON or OFF, toggle the [DISPLAY]/Up ▲ button. When the LCD Monitor is OFF, the status indicator lights up to indicate Power ON status.



Notes:

- The “DATE/TIME” setting screen will appear on the LCD monitor upon its activation in the case of a newly purchased camera or if the camera has not been used for a long time.
- When the camera is in the Play/Erase mode, the LCD monitor cannot be turned off. The still image/ video clip taken most recently will be shown on the LCD monitor. Further, in the case that no image/video clip exists in the memory, the message “NO IMAGE” will be shown on the LCD monitor. When the camera is in the Video Clip Mode, the LCD monitor cannot be turned off either.
- When no operation is performed within a certain time interval (user set value: “1min”, “3min”, “5min”, “10min”, “Cancel”; Default value: “3min”), the camera will automatically turn off.



OPERATIONS** CAMERA MODE****Shooting Basics****Customized Shooting**

- Zooming
- Using Flash
- Using Self-Timer
- Setting the Image Resolution & Quality

 VIDEO CLIP MODE**Shooting Basics**

Customized Shooting is not applicable to the Video Clip and Play/Erase Mode.

 PLAY /ERASE MODE**Play Basics****Menu Settings**


- “SETUP MENU”
- “QUICK VIEW”
- “EV&WHITE BALANCE”

- “SETUP MENU”
- “EV&WHITE BALANCE”

- “SETUP MENU”
- “SLIDE SHOW”
- “ERASE”
- “COPY TO CARD”
- “DPOF”

Setting the various mode:


1. Press the [POWER] button.
2. Press the [MODE] button until the desired mode is displayed.



CAMERA MODE

This mode is used for capturing still images. The images captured will be stored in the camera's internal memory or the memory-card in JPEG file format.

LCD monitor status display



1. Resolution & Quality Indicator

- 1600F Full resolution (1600x1200 Pixels) & Fine quality
- 1600N Full resolution (1600x1200 Pixels) & Normal quality
- 1280 Middle resolution (1280x960 Pixels)
- 640 Low resolution (640x480 Pixels)

2. Memory Card Indicator



Appears when SD Card is inserted.



Appears when MMC card is inserted.

No Indicate Will not be displayed when no memory card is being inserted. (Uses internal memory.)

3. Number Indicator

Number of images that can be stored.

4. Built-in Flash Indicator



The flash fires automatically according to the photography conditions, is suitable for general photography.



Use this mode to avoid the red-eye effect when photographing people in low-light conditions.



Use this mode in the environment where the use of flash is prohibited or under the situation where the distance to the subject is too far away for the flash to have any effect.

5. Self-Timer Indicator



2 sec Self-Timer mode. Shooting begins 2 seconds after pressing the shutter button.



10 sec Self-Timer mode. Shooting begins 10 seconds after pressing the shutter button.

No Indicate Will not be displayed when Self-Timer is not being set.

6. Zoom Indicator

2x

Appears when Digital Zoom is set to 2 times.

3x

Appears when Digital Zoom is set to 3 times.

4x

Appears when Digital Zoom is set to 4 times.

No Indicate Will not be displayed when Digital Zoom is not being set. [1x]

7. EV Level Indicator

Adjust the EV Level by EV & White Balance setting, and the adjusted value will be displayed.

[-2.0 - +2.0]

It is not displayed at default value [0].

8. White Balance Indicator

Adjust the White Balance by EV & White Balance setting, and the adjusted value will be displayed.



It is not displayed at default value "AUTO".

9. Battery Indicator



Battery Life > 40%



20% < Battery Life < 40%



10% < Battery Life < 20%



Battery Life < 10%. Status Led flash 5 sec and then power off.


10. Macro Indicator

It is displayed when the Normal ▲ / Macro 📷 switch dial is set to Macro 📷.

When set to Macro, it is possible to focus the camera on the subject in the proximity of about 45 cm.

Shooting Basics

When the card is inserted into the camera, your captured still images/video clips will be stored in the card's memory. When the card is removed, the internal memory of the camera will be used as the storage media.



Procedures:

1. Get the camera ready. (Refer to “[Getting Started](#)”)
2. Toggle the [MODE] button to select the Camera mode .
3. Turn the Normal / Macro  switch dial to Normal .
4. Frame your subject. You may use either the viewfinder or the 1.5" full color TFT LCD monitor (Toggle the [DISPLAY]/ Up  button to activate or deactivate it)
* We recommend, however, that the viewfinder be used as far as possible to extend battery time since the LCD is highly power consumptive.
5. Press the shutter button fully down.
If the “[QUICK VIEW](#)” function has been set to ON, the image captured will appear on the LCD monitor for a few seconds.
6. To continue capturing, repeat the above steps 4 & 5.

Notes:


- To adjust the Image Quality and Resolution, please refer to “[Setting the Image Resolution and Quality](#)”.
- When the storage memory is full, you may either [erase the images](#) that are no more required, or [insert a new memory card](#).
- The [number of remaining shots](#) shown on the LCD monitor is an approximate value based on the currently set resolution, picture quality and memory size.
- The actual number of remaining shots also differ depending on the shooting conditions. Hence, a single shot may reduce the value by two or not change the value at all. This is not a malfunction of the LCD monitor. Also, upon the camera being turned on, memory adjustments are made and the indicated remaining value may actually be higher than when the camera was last turned off.
- When you take pictures in bright locations or in clear fine weather, lines may appear on the monitor. This is not a malfunction.
- Press the shutter button down steadily.
- When the Status Indicator is lit, shooting/replay is not possible. Wait until the light goes off.
- Never open the Battery/Memory card compartment door when the Status Indicator is lit for this may cause malfunction.
- Please [format](#) new Memory cards with this camera before using them.
- We recommend that you take some test shots to get accustomed to the camera before you actually start.
- We cannot bear any responsibility for an inability to record or replay material normally, in the event of a problem with this camera.
- [Store backups](#) of important images in eg. your personal computer. We cannot bear any responsibility for any loss or alteration to the images stored in the camera’s internal or external memory.
- It is prohibited to use images taken with this camera for commercial purposes without the consent of the copyright owner.



Customized Shooting (CAMERA MODE)

(1) Zooming

This mode allows you to zoom up on your subject, making it appear larger (2x, 3x, 4x) and closer.




Procedures:

1. Ensure that the camera is turned on.
2. Select the Camera mode with the [MODE] button.
3. Press the [OK/ZOOM] button to activate the digital zoom function. The image on the LCD monitor will be enlarged. With each press, the image will change in the sequence of 2x, 3x, 4x and zoom off.
4. Frame your subject. Then, press the shutter button fully down. (For details, see “[Shooting Basics](#)”)

(2) Using Flash

The flash is designed to fire automatically when required. (Default setting: Auto ⚡). To suit the different conditions, however, you can change the flash mode. Press the Flash mode button until the desired flash mode (Auto ⚡, Red-Eye Reduction ⚡👁, Off 🚫) is indicated.



Procedures:

1. Ensure that the camera is turned on.
2. Select the Camera mode with the [MODE] button.
3. Press the Flash mode ⚡/Right ▶ button until the desired flash mode (Auto ⚡, Red-Eye Reduction ⚡👁, Off 🚫) is indicated.
4. Frame your subject. Then press the shutter button fully down. (For details, see “[Shooting Basics](#)”)

Auto Flash



The flash fires automatically according to the photography conditions. It is suitable for general photography.

Red-Eye Reduction (RER)



Use this mode to avoid the red-eye effect when photographing people or animals in low light conditions.

Flash Off



Used where the use of flash is prohibited or when utilizing the night view/indoor lighting for shooting. The flash mode can also be turned off when the distance to the subject is too far away for the flash to have any effect.

Notes:

- When shooting using flash, although the flash fires twice but the actual shoot is at the second flash. The first fire is to determine whether flash is required. The second flash will not be fired if it is not required.
- The red-eye reduction function may have little effect if the subject is not directly facing the pre flash or main flash, or when the distance between the camera and the subject is too far.
- Flash cannot be used during Macro function. It automatically becomes Flash Off.

(3) Using Self-Timer

This unit includes 2 seconds and 10 seconds Self-Timer function. With the 10 seconds Self-Timer function, the photographer too, can get into the frame when taking group pictures. Moreover, when you take pictures in dark locations, the shutter speed may become slow, setting the 2 seconds Self-Timer will prevent the picture from blurring due to shaking of the camera while pressing the shutter button.

Procedures:

1. Ensure that the camera is turned on.
2. Select the Camera mode with the [MODE] button.
3. To activate the Self-Timer, press the Self-Timer /Down  button. The 10 seconds Self-Timer indicator will appear on the LCD monitor as shown on the right. Pressing it again will change to 2 seconds Self-Timer.
4. Frame your subject and press the shutter button. The Self-Timer lamp will start blinking for 10 seconds (slowly in the first 7 seconds and rapidly in the remaining 3) or 2 seconds (rapidly blinking only). At the end of the 10 seconds or 2 seconds, the shutter will be released.




Note:

- When capturing images using the Self-Timer, do stabilize your camera with eg. a camera stand.

(4) Setting the Image Resolution and Quality

Users can choose from four image resolution & quality setting, namely:

To set the Image quality and resolution, press the [RESOLUTION] & Quality/Left  button until the desired setting is indicated.



The number of images that can be stored

The number of images (approximate) that can be stored in the memory card at the current image quality and resolution is reflected on the LCD monitor. Varying the image quality and resolution settings will affect the number of storable images. The following shows the approximate number of storable images based on 8 MB of available memory (when the camera is first turned on), as the image quality and resolution is varied.

Resolution	Quality	Indication on LCD monitor	Initial Estimated Storage with 8 MB Memory
1600x1200	Fine	1600F	10
1600x1200	Normal	1600N	20
1280x960	-	1280	40
640x480	-	640	80

Notes:

- The number of recordable images also varies with the subject and the capacity of the memory card.
- The number of remaining images that can be recorded, shown on the LCD monitor, will decrease by 1 every time you take a new shot. If, however, the file size is too minimal, the number will remain the same after the shot is taken. By the same token, the number will decrease by more than 1 if the file size is too large.



(5) Using Macro

By using the Macro function, it is possible to shoot at a close range (about 45 cm).

Procedures:

1. Ensure that the camera is turned on.
2. Select the Camera mode with the [MODE] button.
3. Turn the Normal ▲/Macro ▼ switch dial to Macro ▼.
4. Frame your subject. Then press the shutter button fully down. (For details, see “[Shooting Basics](#)”)

- | | |
|---|---|
|  Normal Setting | This is usually used when shooting. It is in focus with the subject that is about 1.9 m away. |
|  Macro Setting | For shooting the subject at a close-up range. It focuses in the proximity of about 45 cm. |

Notes:

- If you use the viewfinder to take a picture in Macro mode, the field visible through the viewfinder does not match the field actually photographed because the viewfinder and lens are in different positions. Accordingly, you should use the LCD monitor to take pictures in Macro mode.
- Flash cannot be used during Macro function. It automatically becomes Flash Off.
- Do not turn the Normal /Macro  switch dial unnecessarily. It may become malfunction.
- Please take note not to touch the lens when turning the dial.



VIDEO CLIP MODE

This mode is used for shooting video clips. The video clips will be stored in the camera's internal memory or the memory card in AVI File Format.


Total available recording time

The total available recording time (approximate) is reflected on the LCD monitor. For video clips, the Resolution is fixed at 320x240 and the Image Quality cannot be changed. The following shows the approx. length of recording time based on 8 MB of available internal memory (when the camera is first turned on):

The actual recording time changes in accordance with the images of the Video Clip taken.

Resolution	Quality	Indication on LCD monitor	Initial Estimated available recording time
320x240	-	320	46 sec

LCD monitor status display



1. Resolution & Quality Indicator

320 Video Clip Mode has only one resolution of 320x240.

2. Memory Card Indicator



Appears when SD Card is inserted.



Appears when MMC card is inserted.

No Indicate Will not be displayed when no memory card is being inserted. (Uses internal memory.)

3. Remain Time Indicator

Remain movie time which is display by Count down.

4. [Rec] icon

Appears when recording Video Clip to indicate that recording is in progress.

5. EV Level Indicator

Adjust the EV Level by EV & White Balance setting, and the adjusted value will be displayed.

[-2.0 - +2.0]

It is not displayed at default value [0].

6. White Balance Indicator

Adjust the White Balance by EV & White Balance setting, and the adjusted value will be displayed.



It is not displayed at default value "AUTO".

7. Battery Indicator



Battery Life > 40%



20% < Battery Life < 40%



10% < Battery Life < 20%



Battery Life < 10%. Status Led flash 5 sec and then power off.

8. Macro Indicator

It is displayed when the Normal /Macro switch dial is set to Macro .

When set to Macro, it is possible to focus the camera on the subject in the proximity of about 45 cm.

Shooting Basics




Procedures:

1. Get the camera ready. (Refer to "Getting Started")
2. Toggle on the [MODE] button to select the Video Clip Mode .
3. Adjust the Normal /Macro switch dial to either Normal or Macro to suit the distance of the subject.
4. Press the shutter button to start recording.
5. Press the shutter button again to stop recording.
6. To continue shooting, repeat the above steps 4 to 5.

Video Clip mode



Video Clip recording in progress



Notes:

- When the storage memory is full, you may either [erase](#) the video clips that are no more required, or [insert a new memory card](#).
- The remaining shooting time shown on the LCD monitor is an approximate value based on the currently accessed memory size.
- The actual number of seconds available for shooting also depends on the shooting conditions. The value does not necessarily decrease by the second. Also, upon turning on the camera, memory adjustment is made and the available time may actually be more than when the camera was last turned off.
- When you take pictures in bright locations or in clear fine weather, lines may appear on the monitor. This is not a malfunction.
- Press the shutter button down steadily.
- When the status indicator is lit, shooting/replay is not possible. Wait until the light goes off. (After shooting a video clip, you would have to wait a little while for the pictures to be stored into memory. A few seconds is also required to load the images from the memory to the LCD monitor for replay).
- Never open the Battery/Memory Card compartment door when the status indicator is lit for this may cause damage.
- Please [format](#) new Memory cards with this camera before using them.
- In the Video Clip mode, the following functions are not possible.
 - * Voice/sound recording.
 - * Use of flash.
 - * Self-Timer.
 - * Zoom.
 - * Image Quality setting. (The Video Clip mode resolution is fixed at 320x240.)
 - * Display ON/OFF.
- We recommend that you take some test shots to get accustomed to the camera before you actually start.
- We cannot bear any responsibility for an inability to record or replay material normally, in the event of a problem with this camera.
- [Store backups](#) of important video clips in eg. your personal computer. We cannot bear any responsibility for any loss or alteration to the images stored in the camera's internal or external memory.
- It is prohibited to use video clips taken with this camera for commercial purposes without the consent of the copyright owner.
- Do not turn the Normal /Macro  switch dial unnecessarily. It may become malfunction.
- Please take note not to touch the lens when turning the dial.



PLAY / ERASE MODE

This mode allows you to replay/erase images/video clips stored in the camera's internal or card memory on the LCD monitor.

Play Basics:

1. Turn on the camera.
2. Select the Play/Erase mode with the [MODE] button.




3. The latest captured image (or the starting scene of the latest captured video clip) will be displayed on the LCD monitor. As you press the [DISPLAY]/ Up button, the LCD screen changes as follows:

Still Image:

Image Info. OFF
[DISPLAY]/Up button pressed

Image Info. ON
[DISPLAY]/Up button pressed


Thumbnail display



Video Clip:

Image Info. ON

Thumbnail display
[DISPLAY]/ Up button pressed



4. Press the ◀/▶ buttons to go to the next or previous image/video clip.
5. For video clips only: press the shutter button to play. Press the same button to pause/resume. And press the [OK/ZOOM] button to stop playing.


Thumbnail display function.

During the Play/Erase mode, the captured still images/video clips will be displayed on the LCD monitor. Toggle the [DISPLAY]/Up ▲ button until the thumbnail screen appears. The user can select a thumbnail image using the ▲/▼/◀/▶ buttons. Upon pressing the [OK/ZOOM] button, the chosen image/video clip will be displayed on the LCD screen in full size.



MENU SETTINGS

Pressing the [MENU] button in the various mode will display the respective MENU on the LCD monitor:





CAMERA MODE



VIDEO CLIP MODE



PLAY/ERASE MODE






Using the menus, you can perform various settings for your camera.

Procedures:

1. Use the ▲/▼ buttons to highlight the desired item.
2. The setting of the item with options displayed at the bottom of the screen can be change by pressing ◀▶ button. As for setting of the other items, press [OK/ZOOM] button to proceed.
3. Press [MENU] button to return to the previous screen.



“SETUP MENU” (, , )



“LCD BRIGHTNESS”


Adjusts the brightness of the LCD monitor.
 Setting value: [-5] to [+5] (Interval = 1)
 Default = [0]

“DATE/TIME”


Sets the Date and Time information. When a shot is taken, the date and time of the shot will be recorded on the image file.

To set the date and time:

1. Go into the “SETUP” menu, select the “DATE/TIME” item and press [OK/ZOOM] button.
2. The screen shown below will appear on the LCD monitor.



3. Use the ▲/▼ button to select the desired segment and then use the ◀/▶ buttons to correct the setting. The time setting can be change in steps of 1 minute by the ◀/▶ button, by pressing and holding the ◀/▶ button for more than 5 seconds it can be change in steps of 30 minutes. This is convenient when there is a significant change in value for time setting.



4. When all settings are complete, return to the MENU screen by pressing the [OK/ZOOM] button.

Note:

- Please be sure to correct the date and time setting after battery replacement. To accurately display the date and time information on the LCD monitor, you may need to correct the setting each time you turn on the camera.

“LANGUAGE”

Sets the display OSD language on the LCD monitor.
 The following languages can be selected.

- ENGLISH** : English
- NEDERLANDS** : Dutch

SVENKA	: Swedish
FRANÇAIS	: French
DEUTSCH	: German
ESPAÑOL	: Spanish
PORTUGÊS	: Portuguese
ITALIANO	: Italian

“SOUND”

Enables or disables the sound function.

“ON” : Sounds each time the camera is operated.

“OFF” : Does not sound when the camera is operated.

“FORMAT MEDIA”

This function prepares the memory (internal/external) for use by the camera. When a memory card is inserted, the card will be formatted; In the absence of the memory card, the internal memory will be formatted.

Caution: Formatting will erase all images currently recorded in the memory card.

“FORMAT” : Formats the memory card, erasing all images in the process.

“CANCEL” : Cancels the format action.

“FILE NO. MEMORY”

With this setting set to “ON”, the file NO. does not reset even if the file in the memory has been deleted, the number of the next recorded file will run in sequence with the deleted file number. The number runs until DSC_9999, after which it will be set to DSC_0001.

With this setting “ON”, the recorded file will not overwrite the previously copied file in the same directory when copying into the PC, thus preventing any accidental deletion.

“ON” : Record the lost file number.

“OFF” : Reset file number to DSC_0001.

“AUTO POWER OFF”

This will automatically turn off the camera after the lapse of a certain time interval (set by the user) during which no operation is performed.

“1 min” : Power will be turned off after 1 minute.

“3 min” : Power will be turned off after 3 minutes. (Default)

“5 min” : Power will be turned off after 5 minutes.

“10 min” : Power will be turned off after 10 minutes

“OFF” : Disables the “AUTO POWER OFF” function.

“LIGHT FREQUENCY”

Through this setting, you are able to avoid image flicker due to the fluorescent light.

“50Hz” : Use this if the light frequency of the fluorescent lamp you are using is 50 Hz.

“60Hz” : Use this if the light frequency of the fluorescent lamp you are using is 60 Hz.

“FACTORY SETUP”

Performing this setting restores all settings except “DATE/TIME” to Default. Moreover, recorded files etc. cannot be deleted.

“SETUP” : Restore all parameters to the default setting.

“CANCEL” : Cancel the operation.

Note:

- The settings for “DATE/TIME”, “AUTO POWER OFF”, “LANGUAGE”, “SOUND”, “LIGHT FREQUENCY” and “FILE NO. MEMORY” are retained even after the camera is turned off.



“QUICK VIEW” ()

This feature allows you to view your images on the LCD monitor as soon as they have been taken. After the preview, this camera will return to the Camera mode.

“ON” : Enables “QUICK VIEW”

“OFF” : Disables “QUICK VIEW”

The “QUICK VIEW” setting will be retained even after the camera is turned off.


Note:

- With “QUICK VIEW” set to “ON”, the time interval before the next possible shooting will be prolonged after the current shooting.



“EV & WHITE BALANCE” (📷, 📷)

This screen can be altered by both EV compensation and White Balance. The altered result reflects the taken images in real time, thereby enabling changing of the setting while confirming the images.



EV Compensation

When the object is too dark or too bright, the camera adjusts the brightness to make the object look brighter or darker. This is called EV compensation. The range of the exposure compensation that the user can set is from -2.0 EV to +2.0 EV at 0.5 EV steps.

White Balance

As the intensity of the light changes, our eyes adapt such that white objects will remain white. Digital cameras can also see the white objects as being white by averaging out the light around the object.

You may select from the following settings:

- “AUTO”  : Automatically adjusts the WHITE BALANCE
- “TUNGSTEN”  : Tungsten lighting
- “FLUORESCENT”  : Fluorescent lighting
- “SHADE”  : Overcast, shaded, twilight or evening skies
- “DAYLIGHT”  : Outdoors on a bright day

After completing the setting, press [OK/ZOOM] button to end the setting. The changed setting value, except the default value (EV: 0, White Balance: “AUTO”), will be displayed on the LCD monitor as in the following figure.



Changed EV value

Changed White Balance setting



[\[Back\]](#) [\[Next\]](#)**“SLIDE SHOW” ()**

After selecting “SLIDE SHOW” and set the delay time (with the ◀/▶ buttons) and pressing the [OK/ZOOM] button will start the slide show. Images hitherto captured will be displayed in sequence, at intervals of the user-set delay time [1, 3, 5, 7, 9 “sec”]. To interrupt the slide show, press the [OK/ZOOM] button.

The delay time setting will be retained even after the camera is turned off.




“ERASE” ()

There are two ways to erase still images/video clips:

1. “ERASE ONE”


This will allow you to erase one image/video clip at a time. Use the ◀/▶ buttons to choose the desired still image/video clip to be erased.

A confirmation message “ERASE CURRENT?” will appear on the LCD monitor. Pressing the [OK/ZOOM] button will cause the selected still image/video clip to be erased from memory. To abort this action, press the [MENU] button.



2. “ERASE ALL”

This will allow you to erase ALL recorded still images/video clips in the memory at once. Use the ▲/▼ buttons to choose the “YES” or “NO” option and then press the [OK/ZOOM] button to confirm.



Note:

If no still image/video clip is stored in the memory, a message “NO IMAGE” appears on the LCD monitor.



[\[Back\]](#) [\[Next\]](#)

“COPY TO CARD” ()

This function allows you to copy all captured still images/video clips from the internal memory to the external memory card.

“**COPY**” : Copies all captured still images/video clips from the internal memory to the external memory card.
If a card has not been inserted in the camera, the message “NO CARD” will be displayed on the LCD monitor.

“**CANCEL**”: Cancel the operation.




[Back] [Next]

“DPOF” (Digital Print Order Format) ()

“DPOF” enables you to print the images directly from “DPOF” compatible printers by simply inserting the memory card into the printer after performing the necessary settings.

“ONE BY ONE” : Perform setting to each image one at a time. The following screen will appear, when “ONE BY ONE” is selected and confirmed by pressing the [OK/ZOOM] button.



Select the images by ◀/▶ button, and set the print quantity [0 - 9] by ▲/▼ button. Printing cannot be performed if the setting is [0]. The default value is [0]. After completing all image setting, press [OK/ZOOM] button to confirm and return to the Menu screen.

“ALL 1 PCS” : Sets the print quantity of all the images in the memory to 1 PCS, convenient for printing all the captured images one at a time.
Select “ALL 1 PCS” and execute by pressing the [OK/ZOOM] button.

“DELETE ALL” : Deletes all the “DPOF” setting being set.
Select “DELETE ALL” and delete by pressing the [OK/ZOOM] button.

Note:

- “DPOF” setting is not possible in Video Clip.

The “DPOF” settings are retained even after the camera is turned off.



TRANSFERRING IMAGE DATA TO THE COMPUTER

Before image data transfer, you need to connect the camera to your computer with the supplied USB cable and Windows 98/98SE users need to install the camera drivers included in the supplied CD-ROM.

Once the camera is connected to the PC, power will be supplied to the camera through the USB cable.

System Requirements

Before installing the Camera Driver and Application software, make sure your system meets the following system requirements:

- Microsoft® Windows® 98/98SE/Me/2000/XP (Pre-installed Model)
- Intel® Pentium® Processor 166 MHz or higher
- Free USB Port
- Minimum RAM: 32 MB (Windows XP: 128 MB)
- 250 MB of available hard disk space
- Color display: 800x600 or better
- CD-ROM drive

Note:

- Please connect the camera directly to the PC. Camera performance is not guaranteed in the case that the camera is connected to the PC via a USB Hub.

Connecting the Camera to Your Computer

For Windows 98/98SE users, it is necessary to install the Mass Storage Driver contained in the supplied CD-ROM before connecting the camera to the PC for image data download. For Windows Me/2000/XP users however, this is not necessary. (Proceed to [connect the camera to the PC](#))


Installation Procedures:

1. Place the supplied CD-ROM into the CD-ROM drive.
2. A Setup Menu screen will appear on the PC monitor as shown below. Click on "USB Mass Storage Driver install for Windows 98/98SE".




3. Follow the on-screen instructions to complete the installation.
4. Reboot your computer.

Once you have installed the appropriate Camera Driver(Windows 98/98SE), you are now ready to connect the camera to the PC for download. Follow the procedures below:




Procedures:

1. Turn off the camera.
2. Open the USB port cover. Plug the smaller connector of the USB cable into your camera's USB port.
3. Plug the other end of the USB cable to your computer's USB port.
4. The camera powers ON automatically, and the "USB MODE" screen appears on the LCD monitor as follows:



Select "DISK DRIVE" and press the [OK/ZOOM] button.

5. Your computer will recognize the camera as a newfound hardware. Setup for this new hardware will proceed automatically. This Setup process is performed only once and will not be necessary for subsequent connections. When complete, your camera will be indicated as a "Removable Disk" in your computer's "My Computer" folder.



(This screen is from Windows XP)

Note:

For Windows XP, the computer will display a message screen as below. In this case, please click on “Open folder to view files” and proceed by clicking the “OK” button.




(This screen is from Windows XP)

Downloading Pictures

1. Click on the “My Computer” icon on your PC screen. You will then see a drive icon labeled “Removable Disk”.


2. Double click on “Removable Disk”. A new window with a “DCIM” folder icon opens.



(This screen is from Windows XP)


* If this icon is not displayed, your camera has not been properly connected to the computer. In this case, go to [“Connecting the Camera to Your Computer”](#) and repeat the procedures.

3. Double click on the “DCIM” folder icon. A new window with a “***JVC GC” folder icon opens (** represents a number in the range of 100~999). Your recorded images will be in this folder.



(This screen is from Windows XP)

4. You can then copy the whole folder or specific files in the folder (double click on the icon to reveal the files) into your computer's hard drive, or any other storage media available in your PC system. Just select the folder or files and use the usual "cut" and "paste" functions available in the "Edit" menu.



(This screen is from Windows XP)

Notes:

- While the camera is connected to your computer, the camera will not allow you to capture images. You will also not be able to view the images on the camera's LCD monitor.
- Please refer to your computer's instruction manual to ascertain the procedures for copying and shifting of files.

Using the Camera as a USB PC Camera

This camera can also act as a video camera for your PC, allowing you to hold videoconferences over the internet or corporate intranet.

Before you start, you will have to install the WebCam Driver into your computer, regardless of your PC's OS version (Windows 98/98SE/Me/2000/XP).

To install the WebCam Driver:


1. Place the supplied CD-ROM into the CD-ROM drive.
2. A Setup Menu screen will appear on the PC monitor as shown below. Click on "Webcam Driver Install".



3. Follow the on-screen instructions to complete the installation.
4. Reboot your computer.

Using your camera as a USB PC camera with Microsoft Netmeeting or Windows Messenger:

1. Make sure you have installed the WebCam Driver.
2. Make sure that your camera is turned off. Then, connect the USB cable to the camera and your computer's USB port. The camera powers ON automatically.
3. The "USB MODE" screen appears on the LCD monitor as follows:



Select "PC CAMERA" and press the [OK/ZOOM] button.

4. Your computer will recognize the camera as a newfound hardware and Setup will proceed automatically. This Setup process is performed only once and will not be necessary for subsequent connections.

Note:

For Windows XP, the computer will display the warning screen as below several times when recognizing the camera. In this case, please click the "Continue Anyway" button.



(This screen is from Windows XP)

The setup menu and message used for the explanation are in English. Please be aware that different message will appear if other language is selected during software installation.

5. Launch the PC Camera Application software (Microsoft Netmeeting/Windows Messenger) and follow the instructions displayed on the computer monitor.
6. Start video conferencing.
7. After the video conference, be sure to switch off the computer first before disconnecting the camera from it.

Notes:

- The PC camera Application software is not included in the CD-ROM. Use a commercially available videoconferencing software such as the above mentioned Microsoft Netmeeting or Windows Messenger. For more information about video conferencing software, please refer to the respective software's help functions.
- To videoconference over the Internet or LAN, you would also need networking devices such as modems, speakers and microphones.
- The other party you wish to videoconference with must also have Microsoft Netmeeting/Windows Messenger running in order to start the videoconference.



TROUBLESHOOTING

When the camera does not work:**Possible cause**

- Power unintentionally cut off.
- Power cut off due to camera's [Automatic Power Off](#) feature.
- Battery direction is wrong.
- The batteries are weak.
- Battery performance deterioration due to low temperature.
- Camera is connected to PC. (When connected to PC, the camera will not be able to shoot).
- Condensation inside camera.

Rectifications

- Press the [\[POWER\] button](#) to turn the camera on.
- Press the [\[POWER\] button](#) to turn the camera on.
- Rearrange the batteries in the correct position.
[Replace batteries.](#)
- Warm up the batteries to some extent by, for example, rubbing them against a soft surface before use.
- Detach the camera from the PC after [image-data download](#).
- Dry the camera before turning on the power.

When the flash does not work:**Possible cause**

- Camera is set at the Video Clip or Play mode.
- Flash is set to off.
- Shooting in bright light situation.

Rectifications

- Set camera to [Camera mode](#).
- Set to Auto/Red-eye.
- The flash does not fire in bright light situation.

When the LCD Monitor does not show well:**Possible Cause**

- The camera is held under bright sunlight.
- The LCD monitor is not activated.

Rectifications

- Use your hand to cover the monitor from sunlight. Alternatively, use the [viewfinder](#).
- Press the [\[DISPLAY\]/Up ▲](#) button to activate the monitor.

When you are unable to shoot:**Possible Cause**

- Power is low or off.
- Flash re-charge after shooting is not yet complete.
- Internal or card memory full.
- The card is write protected.

Rectifications

- Check [battery level](#). Replace if necessary.
- Release the shutter button, wait till the [Status Indicator](#) is unlit, then shoot again.
- Erase the images no longer required, [transfer](#) them to your PC or [insert a new memory card](#).
- Use a new card or disable the write protection. (only for SD card)

When you are unable to replay the images:**Possible Cause**

- Power is low or off.
- Camera is set to the wrong mode.
- The pictures have not been saved in memory.

Rectifications

- Check [battery level](#). Replace if necessary.
- Set camera to [Play mode](#).
- Follow the instructions in this manual, shoot again and replay.

When you are unable to [Format](#) or [Erase](#):**Possible Cause**

- The card is write protected.

Rectifications

- Disable the write protection. (only for SD card)

When photographs turn out too bright:

Possible Cause

The subject was too bright.

Rectifications

Adjust the [exposure](#) or change the angle of shot.

When photographs turn out too dark:

Possible Cause

The flash was obstructed by fingers or other objects.

The subject was too far from the camera for the flash to be effective.

Flash is set to off.

Rectifications

Adjust the angle of shot and remove obstructive objects.

Move closer to the subject. Alternatively, turn off the [flash](#) and use a tripod stand.

Set to Auto/Red-eye.

When the color of the Images appear odd:

Possible Cause

No white area on the subject.

White Balance setting incorrect.

Rectifications

Introduce a white item or set the [White Balance](#) according to the lighting condition.

Set the [White Balance](#) according to the lighting condition.

When parts of the images are missing:

Possible Cause

The lens is partially covered by fingers or the strap.

Shooting distance too close.

Rectifications

Remove obstructing fingers or strap from lens.

Use the [LCD monitor](#) and the [zoom](#) function.

When the image is out of focus:

Possible Cause

Camera movement during still image capture.

The lens is dirty.

Photographer was standing in front of the camera when pressing the shutter button (Self-Timer shots).

Flash is off even when the lighting condition is poor. As exposure time is prolonged, camera movement will cause the image to be off focus.

The subject is too near.

Rectifications

Press the [shutter](#) button down steadily.

Use a lens blower (sold in the market) to rid the lens of dust. Then wipe with lens cleaning paper.

Do not stand in front of the camera. Press the [shutter](#) button while looking through the viewfinder.

Either use a tripod stand, or use the [flash](#).

Shoot at a distance of more than 1.9 m.



CAMERA SPECIFICATIONS

Image Sensor	2.0 Megapixels CMOS
Color	10-bit Color (RGB)
Image Resolution & Quality	Camera mode: 1600x1200 pixels Fine quality 1600x1200 pixels Normal quality 1280x960 pixels 640x480 pixels Video Clip mode: 320x240 pixels
Memory	Internal: 8 MB External: SD or Multimedia Card
File Format	JPEG (EXIF 2.1), DPOF, AVI (Motion-JPEG)
Number of storage (Initial Estimated Storage with 8MB internal memory)	Camera mode: 1600x1200 pixels Fine quality (Approx. 10 pcs) 1600x1200 pixels Normal quality (Approx. 20 pcs) 1280x960 pixels (Approx. 40 pcs) 640x480 pixels (Approx. 80 pcs) Video Clip mode: 320x240 pixels (Approx. 46 sec) <ul style="list-style-type: none"> • The number of recordable images also varies with the subject and the capacity of the memory card. • The number of remaining images that can be recorded, shown on the LCD monitor, will decrease by 1 every time you take a new shot. If, however, the file size is too minimal, the number will remain the same after the shot is taken. By the same token, the number will decrease by more than 1 if the file size is too large.
USB Frame Rate (WebCam)	320x240 (USB1.1)
Recording Media	SD or Multimedia card
Lens	Fixed focus (2x, 3x, 4x digital zoom), F 2.8 f = 9.96 mm (equivalent to 51.3 mm on a 35-mm still camera)
Focus Range	Normal: 1.9 m ~ infinity, Macro: 40 cm ~ 50 cm
Shutter Speed	1/15 ~ 1/1000 seconds
Exposure Control	Auto Manual: 0.5 EV step, -2.0 ~ +2.0
White Balance	Auto / Sun / Shade / Fluorescent / Tungsten
Flash	Built-In: Auto, Flash Off, Red-eye reduction
Self-Timer	10 seconds delay, 2 seconds delay
Software	MGI Photo Suite IV SE and Photo Vista 2.02
Language	English, French, Spanish, Traditional Chinese, German, Dutch, Swedish, Portuguese, Italian
LCD monitor	1.5" color TFT LCD
Connectors	USB port (Mini B type)
Weight	About 110 g (without battery and SD card)

Dimension

Approx. 82 mm x 60 mm x 30.5 mm
[3.2 inches (W) x 2.4 inches (H) x 1.2 inches (D)]

* Design and Specifications are subject to change without notice.

